



Calhoun: The NPS Institutional Archive
DSpace Repository

Theses and Dissertations

1. Thesis and Dissertation Collection, all items

1977

A microprocessor controlled automatic data logging system (ADL)

Casko, John David

<http://hdl.handle.net/10945/18201>

Downloaded from NPS Archive: Calhoun



Calhoun is the Naval Postgraduate School's public access digital repository for research materials and institutional publications created by the NPS community. Calhoun is named for Professor of Mathematics Guy K. Calhoun, NPS's first appointed -- and published -- scholarly author.

Dudley Knox Library / Naval Postgraduate School
411 Dyer Road / 1 University Circle
Monterey, California USA 93943

<http://www.nps.edu/library>

A MICROPROCESSOR CONTROLLED AUTOMATIC
DATA LOGGING SYSTEM (ADL)

John David Casko

NAVAL POSTGRADUATE SCHOOL

Monterey, California



THESIS

A MICROPROCESSOR CONTROLLED AUTOMATIC
DATA LOGGING SYSTEM (ADL)

by

John David Casko

June 1977

Thesis Advisor

David Caswell

Approved for public release; distribution unlimited.

T180064

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE

READ INSTRUCTIONS
BEFORE COMPLETING FORM

1. REPORT NUMBER		2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) A MICROPROCESSOR CONTROLLED AUTOMATIC DATA LOGGING SYSTEM (ADL)		5. TYPE OF REPORT & PERIOD COVERED Master's Thesis June 1977	
7. AUTHOR(s) John David Casko		6. PERFORMING ORG. REPORT NUMBER	
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Postgraduate School Monterey, California 93940		8. CONTRACT OR GRANT NUMBER(s)	
11. CONTROLLING OFFICE NAME AND ADDRESS Navla Postgraduate Schaoool Monterey, California 93940		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office) Naval Postgraduate School Monterey, California 93940		12. REPORT DATE June 1977	
		13. NUMBER OF PAGES 123	
		15. SECURITY CLASS. (of this report) Unclassified	
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release, distribution unlimited.			
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)			
18. SUPPLEMENTARY NOTES			
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) microprocessor, digital control, data logging, data acquisition			
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This paper describes a digital, microprocessor controlled data acquisition system which optimizes man/machine communications. The processor provides digital feedback control, data collection over any number of channels (up to 8), 32 BIT floating point (7 significant digit) mathematics, and			

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

a variety of output formats. The main features of the device are the ability to work in any numerical unit desired by the user, mathematical noise filtering and automatic feedback control.

The particular application under consideration is automatic data collection and angle-of-attack control of a subsonic wind-tunnel. Data are presented to demonstrate the data logging capabilities of the system.

Approved for public release; distribution unlimited.

A MICROPROCESSOR CONTROLLED AUTOMATIC DATA LOGGING
SYSTEM (ADL)

by

John David Casko
Lieutenant, United States Navy
B.S., Kansas University, 1970
M.S., University of West Florida, 1972

Submitted in partial fulfillment of the
requirements for the degree of

MASTER OF SCIENCE IN AERONAUTICAL ENGINEERING

from the
NAVAL POSTGRADUATE SCHOOL
June 1977

ABSTRACT

This paper describes a digital, microprocessor controlled data acquisition system which optimizes man/machine communications. The processor provides digital feedback control, data collection over any number of channels (up to 8), 32 BIT floating point (7 significant digit) mathematics, and a variety of output formats. The main features of the device are the ability to work directly in any numerical unit desired by the user, mathematical noise filtering and automatic feedback control.

The particular application under consideration is automatic data collection and angle-of-attack control of a subsonic wind-tunnel. Data are presented to demonstrate the data logging capabilities of the system.

TABLE OF CONTENTS

I.	INTRODUCTION.....	9
	A. BACKGROUND.....	9
	B. DISCUSSION.....	10
II.	SYSTEM DESCRIPTION.....	11
	A. REQUIREMENTS.....	11
	B. DEVICE SELECTION.....	12
	C. INPUT/OUTPUT DEVICES.....	12
	D. FUNCTIONAL ARCHITECTURE.....	13
	1. General.....	13
	2. Internal.....	14
III.	COMMAND WORDS.....	20
	A. DATA DEFINITION.....	21
	1. UNIT.....	21
	2. WAIT.....	21
	3. SET SCAN.....	22
	B. ACQUISITION COMMANDS.....	22
	1. READ.....	22
	2. SCAN.....	23
	3. MOVE.....	23
	4. RUN.....	24
	C. FILE MAINTENANCE.....	25
	1. EDIT.....	25
	2. FILE.....	25
	3. DUMP.....	26
	4. MTEST.....	26
	5. CNTRL-A.....	26
	6. CNTRL-R.....	27
	7. CNTRL-C.....	27
	8. CNTRL-Z.....	27
	9. RUBOUT.....	27

D. EXAMPLES.....	28
IV. WIND TUNNEL APPLICATION.....	38
V. SOFTWARE DESIGN.....	42
VI. RECOMMENDATIONS.....	99
Appendix A: GLOSSARY.....	101
Appendix B: VENDOR DATA.....	104
Appendix C: MATHEMATICS PACKAGE.....	113
LIST OF REFERENCES.....	122
INITIAL DISTRIBUTION LIST.....	123
LIST OF FIGURES.....	7

LIST OF FIGURES

1.	PROICG 805 System layout.....	16
2.	ADL/805 interface.....	17
3.	A/D conversion system.....	18
4.	Numerical data conversion methods.....	19
5.	Data definition examples.....	30
6.	SCAN and RUN examples.....	31
7.	Improper input example.....	32
8.	EDIT and FILE examples.....	33
9.	Wind-tunnel tare data.....	34
10.	Wind-tunnel data run.....	35
11.	Plot of wind-tunnel data.....	36
12.	Exponential format examples.....	37
13.	Photos of ADL components.....	40
14.	Angle-of-Attack feedback loop.....	41
15.	Noise and glitch filter logic.....	43
16.	'UP' relay driver logic.....	44
17.	Overshoot/undershoot correction logic.....	45
18.	External device control logic.....	46
19.	Run routine logic (part 1).....	47
20.	Run routine logic (part 2).....	48

ACKNOWLEDGEMENT

The author takes this opportunity to express his most sincere thanks to Cdr. David Caswell, USN, thesis advisor, for his logistic support and patience; to Dr. Louis Schmidt, co-advisor for the physical design of the ADL system and wind tunnel interface; to Ted Dunton, chief technician for his tireless and cheerful troubleshooting.

Special thanks go to Charles Lembo, president of CYBERDATA Corporation, Monterey, California for his generous loan of equipment and facilities during a period of hardware malfunction.

Most of all, thanks to my family for their endless support and understanding.

I. INTRODUCTION

A. BACKGROUND

The use of microprocessors (U-P) to control various analog and digital devices has grown exponentially in the past two years. Applications range from TV tennis games and 'smart' traffic lights, to industrial plant monitors and high speed data handling. The state-of-the-art U-P at the time of this writing is the INTEL 8748. This single integrated circuit contains:

1. Central Processing Unit (CPU)
2. 1K bytes of erasable, programmable, read-only memory (EPRCM)
3. 64 bytes of random access memory (RAM)
4. 8-BIT interval timer/event counter
5. clock driver

In addition, this device draws only 150 milliampere (mA) at 5 volts (V).

Microprocessors have greatly enhanced the important technological application called DISTRIBUTED INTELLIGENCE. For example, routine - but time consuming - chores such as parallel to serial data conversion, x-y plotting, equipment polling, etc. can be controlled on site. Engineering analysis of such large interconnected subsystems reduces to a 'black box' problem rather than the more complex problem

of centralized command and control.

B. DISCUSSION

This paper describes the development and construction of an automatic data logging system (ADL) which is configured via software to suit a particular application. The software modification is dynamic in nature, which means that the system operator needs only to type in a few simple commands to change the system input/output (I/O) to measure volts, feet, psi or any other quantity directly without external hardware modification or adjustment. The requirements for the system and an overall description of the ADL hardware are given in chapter II. Chapter III discusses the command words available along with examples of actual output. Chapter IV presents a specific application of the system. Guidelines for interfacing the digital feedback control function with various types of equipment are also given. Chapter V contains the software assembly listing as well as flowcharts and explanations of the more important routines. Chapter VI discusses the use of U-P development systems and gives recommendations for software development. Appendix A is a glossary of U-P and data acquisition terminology which is used throughout the paper.

II. SYSTEM DESCRIPTION

A. REQUIREMENTS

The purposes of a data logging system are twofold. First, the system must be able to take readings from a variety of physical devices. Second, these readings must be converted into a form suitable for data reduction and human interpretation. The obvious use of such a system is taking data over extremely long or extremely short time periods, filtering out noise, controlling external events and providing tabular and/or graphical output. With the above in mind, the following requirements are defined:

1. 8 channels of analog input
2. 1 channel for digital feedback control of some external device.
3. Plain language man/machine interface via serial data transmission.
4. Manual and automatic data acquisition functions.
5. Limited data manipulation.
6. Multiplexed digital voltmeter function.
7. Limited text file storage and editing.

It should be pointed out that the above requirements were defined with the wind-tunnel control function in mind (ch. IV). Nevertheless, the concepts may be extended to other applications with minor software modifications.

B. DEVICE SELECTION

A strictly hardware-oriented implementation of the system requirements was not a valid alternative due to the inherent inflexibility of such designs. Large scale computer installation was prohibitive from cost and under-utilization considerations. It was therefore decided to use an available microprocessor - the INTEL 8008 - to implement all logic and data manipulation functions. This U-P device is the heart of the PROLOG Corporation 805 microprocessor system. Figure 1 is a schematic of the 805 system layout as modified for this project. Appendix B presents vendor specifications for same. Figure 2 shows the overall system layout including the command and communications links between the system components and the operator.

C. INPUT/OUTPUT DEVICES

The man/machine interface was the most difficult task to implement. The major difficulty was not in the physical interface, but the language used for two-way communications. A software driven ASR-33 Teletype was used for command entry, data presentation, and test functions. Although teletype driving wastes CPU time, the time delays involved are still much less than the mechanical time delays of the relays and driving motors which the U-P is controlling.

A group of eight HEWLETT PACKARD 5082-7302 display lights was used to implement the digital voltmeter function. This display is used to set amplifier gains, set nulls and to verify that data present on a particular input are being

processed by the system. The light display is controlled via software to display data in volts.

Up to eight channels of analog data may be multiplexed (DATEL MM-8) into the sample-and-hold unit (DATEL SHM-4), as shown in figure 3. The analog-to-digital (A/D) converter (DATEL ADC-149) has 14-BIT resolution over a 20-volt range. These three devices are also driven via software in order to provide various time delays between data samples. The time delays are utilized to mathematically filter out low level noise and A/D glitches from the system. Appendix B contains vendor data for the above mentioned devices.

D. FUNCTIONAL ARCHITECTURE

1. General

The primary advantage of a software configured system is that its processing functions and I/O can be modified without external hardware adjustment. This implies that the system possesses a 'general purpose' quality. However, a compromise must be made between a completely general system and one which can be easily implemented by an operator who has little knowledge of the operating system (OS) software or of the dynamics of the system from which this person is collecting data. In order for the data logging system to be used effectively by students in a variety of engineering disciplines, the OS was set up to optimize man/machine interaction. Thus, the operator has no control over such parameters as relay and drive motor transportation lag. These particular system parameters are fixed (see chapter IV) but still provide wide applications such as probe placement and angle setting. Although obvious,

it is worth mentioning that the feedback controlled movement of an external device may not be coincident with data acquisition and reduction, as the U-P can perform only one function at a time. In general, the internal data handling of the microprocessor is transparent to the user.


2. Internal

Figure 4 is a flowchart of the basic numerical data conversion processes. Note that two levels of conversion take place. The first level converts data from the 14-BIT binary provided by the A/D converter into a numerical voltage between -10 and +10 volts. This interpolation routine is called before any raw data are processed. The next level of conversion is accomplished with a scaling routine which changes voltage units into any unit desired by the user. If the user does not specify a particular scaling factor, the system defaults to volts for all I/O presentations. Scaling factors can be changed at any time, on any of the input channels; different channels may have different scaling factors.

The mathematics package used is from the INTEL Users Library and is discussed in Appendix C. Although the math package performs all operations with 7 significant digits, numerical output is rounded to 4 significant digits (with choice of decimal or exponential notation). This was done to improve readability of tabulated output and to permit all eight channels to be printed in the limited space provided by the teletype. The only exception is the DUMP routine (ch. III), which always outputs 7 digits. This is because scaling factors of up to 7 digits can be entered by the operator (also fig. 4).

The decimal format presents data between 0.0001 and

9999. The exponential format presents 4 significant digits between $1.000 \text{ E}-28$ and $10.00 \text{ E}+27$. All numerical entries by the operator can be in either format , with the exception of channel numbers, which are only single digit integers.



- A - 2K EPROM
- B - CPU
- C - 4K RAM
- D - Input ports
- E - Output ports
- F - Serial interface
- G - Power supply
- H - Sockets
- I - Card cage

Modular construction
of the U-P components
enhances expansion.

Figure 1 - PROLOG 805 SYSTEM LAYOUT




Figure 2 - ADL/805 INTERFACE




Figure 3 - A/D CONVERSION SYSTEM




Figure 4 - NUMERICAL DATA CONVERSION METHODS

III. COMMAND WORDS

This chapter defines the commands which the operator may use to communicate with the ADL. A brief explanation of the word is presented; then the rules for its usage and the ADL response is given. The commands are organized into three categories:

1. DATA DEFINITION: Used to set scaling and delay parameters, and to store the sequence of channels to be scanned.
2. ACQUISITION: These commands start various types of acquisition processing, including the voltmeter and feedback control routines.
3. FILE MAINTENANCE: These are convenience features which provide simple text editing and printing of repetitious table headings. They also provide abort capability and correction capability for misspelled words.

Note that command words are entered in upper case just as they appear in the following paragraphs. When the ADL is ready for a command, it prompts with the symbol >. The command word is then entered followed by pressing the RETURN key. In all examples given, the ADL-generated text is shown in parentheses for illustration purposes only. Section D of this chapter presents copies of actual printout from typical runs in order to further clarify the use of the commands.

A. DATA DEFINITION

1. UNIT

This command is normally the first used. It enables the user to specify a scaling factor so that all data I/O will be in any desired unit. A typical sequence of commands could appear as follows:

```
(>) UNIT  
(CHANNEL =) 1  
(UNIT/VOLT) 10.5  
(CHANNEL =) 6  
(UNIT/VOLT) .2  
(CHANNEL =)  
(>)
```

Thus the user has specified a scaling factor of 10.5 for channel 1 and .2 for channel 6. The abort command was then used to terminate the routine. The ADL responded with > when again ready to accept commands. The result of the above is that, for example, a 3-volt input on all channels will print out as 3.000 on channels 0,2,3,4,5,7; as 31.50 on channel 1 and as .6000 on channel 6.

2. WAIT

this command is used to set a known time delay between sets of data points. The ADL takes 128 data points from each channel and computes an average before a value is printed. Thus, the effects of noise and A/D glitches are

minimized. Because it takes 1 millisecond (ms) for the ADL to set up the multiplexer for a different channel, the WAIT delay must be used with caution in an environment which exhibits periodic noise. If only one channel is scanned, the time between data points will be as entered. However, if all 8 channels are scanned the time between data points on any channel will be the desired time plus 8 ms (1 ms for each channel).

3. SET SCAN

SET SCAN is a dual purpose routine. First of all, if a WAIT command has not been issued it will default to 15 ms and send a message to the operator; otherwise, it proceeds to the next step. The operator is then given the opportunity to specify the type of output format, namely, exponential or decimal. Second, the ADL asks the operator to input the channels to be scanned in the desired sequence. Section D presents some typical examples of SET SCAN usage.

B. ACQUISITION COMMANDS

1. READ

This is the command used to start the voltmeter function. A typical entry would look like:

(CHANNEL =) 3

When the RETURN key is pressed, the digital display will follow the data on channel 3 (in volts). The display is updated every 10 ms and takes the data through a 43 microsecond window. When the display is in operation, any

noise on the input will show up as a rapidly changing digit. This is unlike most digital voltmeters which integrate the input over a small time interval and present an average reading. This integration process may effectively mask any noise down to fairly low frequencies, depending on the voltmeter being used.

The main use of the above function is to set gain limits on the inputs. To transfer command back to the user, any key on the teletype can be pressed. The ADL responds with > and is then ready for another command.

2. SCAN

SCAN is used to manually control the tabulation of data. Upon command entry, the ADL checks to see if channel assignments have been made via the SET SCAN routine. If the check is negative, a message is sent to the operator and the routine is aborted. If the check is positive, headings are printed out with the proper spacing for the desired numerical format. The ADL then waits for a RETURN at which time a set of data is taken, averaged and printed out with the proper scaling factor applied. The printer carriage is then positioned at the end of the line of data so the user may enter any comments. The next set of data is taken when the RETURN key is pressed. Before each line of data is printed, a three digit counter, called the coordination number, is incremented automatically. The SET SCAN routine is used to reset this counter to zero (also automatic). Thus, repeated calls to SCAN or RUN will keep the counter indexing properly. The SCAN routine is terminated by entering the abort command.

3. MOVE

Channel 0 was internally defined as the feedback channel for ADL control of some external device. The operator inputs the desired position (speed, angle, etc.) and the ADL will provide the logic necessary to drive the device to within 4 A/D counts; 1 A/D count is equal to 1.22 millivolt (mV). A sample is taken every 0.8 ms so the maximum slew rate at the input is limited to 6.1 mV/sec in order to guaranty convergence. This routine is used mainly to ensure slew rates are not excessive and that external device movement does not exceed acceptable limits. Chapter V presents a detailed flowchart of the feedback logic used in the ADL.

4. RUN

RUN internally calls the SCAN and MOVE routines in repetition in order to automate the tabulation of data at many different positions of an external device. A typical data entry sequence for RUN could be:

```
(START POSIT =) 10.0  
(STOP POSIT =) 7.5  
(INCREMENT =) .5
```

Note that the start position does not need to be less than the stop position. Also note that the incremental movement is in absolute value. Upon execution (the RETURN key) the ADL prints out column headings as defined by the SET SCAN routine, slews the external device to the start position and starts tabulating data at each of the positions between START and STOP. When the stop position data have been printed out, command is returned to the operator.

C. FILE MAINTENANCE

The following commands are used to input text information and comments.

1. EDIT

When the same heading information will appear as part of the documentation of each run, EDIT is used to enter this information for later use. After the desired text has been entered, the LINE FEED (L/F) key is pressed, followed by the RETURN key. The L/F is needed internally to mark the end of the file; this is the only routine that terminates with other than just the RETURN key. If the L/F key were not used, the entire buffer space (256 characters) would print out. At this time, if the END-OF-FILE symbol were not detected, an error message would be sent to the operator.

The EDIT mode can also be used to change or correct the text at any time. The routine is entered via the command word; the CONTROL and Z keys (cntrl-Z) are pressed simultaneously to step through the file. When the proper place in the text is reached, the RUBOUT key is pressed, then the new character is entered. Note that this entry is not inserted between two characters, but rather it overwrites; any number of characters can be reentered. In order to exit the routine without using the L/F key (which would truncate the text), the cntrl-A keys are used. Section D shows the construction and edit of a file.

2. FILE

The text entered with the EDIT command is printed out upon execution of FILE. Two lines are skipped automatically at the beginning and at the end of the file.

3. DUMP

Execution of DUMP will cause the contents of the conversion factor buffer to be printed on the teletype. This enables the user to verify the scaling factors which are being applied to each channel. Numbers are printed with 7 significant digits.

4. MIEST

This command is executed automatically upon system reset or when power is applied. All the ram area is tested by first writing 00H to each location, reading it back and comparing the result with 00H; the same process is repeated with FFH (Appendix C contains an explanation of hexadecimal notation). If an error were detected, the contents of the bad location would be printed out along with its address. This enables the operator to identify the particular circuit component which has malfunctioned. The routine can also be entered as a command, but use of this function resets all default values just as a system reset.

5. CNTRL-A

The abort command is used to terminate execution of all routines except RUN and READ. When the cntrl-A keys are used, command is transferred back to the operator and the system responds with a >. The RUN routine can only be

terminated with a system reset; the READ routine is terminated by pressing any of the teletype keys.

6. CNTRL-R

Pressing these two keys causes the phrase RUN NO. to be printed. The keyboard is then opened for the insertion of any desired alpha/numeric single line sequence.

7. CNTRL-C

This command causes **** to be printed in order to flag a comment. Note that this is a command routine and can only be entered after a > prompt by the ADL.

8. CNTRL-Z

Pressing these keys causes an internal counter to advance forward through the input buffer. In this manner, the contents of memory can be displayed (see EDIT).

9. RUBOUT

This key is used mainly to correct spelling errors or to correct data entries without aborting a routine. For example, assume the operator wants to enter SCAN but notices that SVAN has been typed by mistake. The RUBOUT key is pressed three times. Each time it is pressed, the previously entered character is printed and an internal counter counts backwards through the input buffer. The operator then retypes the correct letters (CAN) and the correction is complete. The teletype entries would then look like:

SVANNAVCAN

When executed, the ADL will only see SCAN.

Command word recognition is accomplished by summing the binary codes of each of the letters of the word. The result is then compared with a list of valid sums which are contained in memory (check-sum). Since the result of a summation does not depend on the order of the addends, the letters of the command word may be entered in any order (e.g., SCAN, NACS, etc.). Although this method could lead to ambiguity problems, the vocabulary of the ADL is small enough to prevent such an inconsistency. Any command, text or data entry can be edited with the RUBOUT key at any time.

D. EXAMPLES

The figures following this section are copies of actual ADL sessions. All ADL-generated messages are underlined the first time they appear for illustration purposes only.

Figure 5 shows a DATA DEFINITION sequence. The UNIT command was used to override the volt default on channels 0,1 and 2. The SET SCAN routine was used to select decimal format and to sequence channels 6,7,0,3,6. Note that the channels do not need to be in any particular sequence and that one channel may be used more than once. The use of a channel more than once enables the user to check the effectiveness of the noise filtering algorithm in a particular application. In this case, data taken on the first channel 6 scan will be 19 ms out of phase with the second channel 6 scan (15 ms for the delay parameter and a 1 ms intercycle delay for each channel). The operator then used the wait routine to change the wait parameter to 3 ms.

The subsequent call to the SET SCAN routine did not produce the default message (labeled A on the previous call).

Figure 6 shows a typical SCAN sequence which resulted from the commands entered from fig. 5. SCAN was used to take 5 sets of data, then RUN was used to take 5 sets. It is important to note that channel 0 must be included in the SET SCAN definition before RUN is executed. This is because channel 0 is the feedback path for the digital control functions.

Figure 7 shows the ADL response to improper inputs. After a reset, the operator tried to execute SCAN without first defining the channel sequence. The next example in this figure shows an invalid command followed by some examples of using the RUBOUT key to correct various entries.

In fig. 8 the operator did not use a LINE FEED/RETURN sequence to mark the end of the text. The resulting call to FILE is then shown.

Figures 9 and 10 present the data from a wind tunnel calibration session. Figure 11 is a graph of the lift data (channel 2) versus angle-of-attack (AOA, channel 0). Notice that the scaling factors for channels 0 and 2 were selected so that their respective output would be read in degrees and pounds directly. Figure 12 shows a run which utilized exponential format.

*** RESET: ALL CHANNEL I/O IN "VOLTS" ***

> UNIT

CHANNEL = 0

UNIT/VOLT = .1

CHANNEL = 1

UNIT/VOLT = 500.

CHANNEL = 2

UNIT/VOLT = 144

CHANNEL =

(A) > SET SCAN

DELAY BETWEEN DATA POINTS = 15 MS (DEFAULT)

"E" FORMAT(Y OR N) ? N

INPUT CHANNELS IN DESIRED ORDER

6,7, 0 3 6

WHEN READY TO TAKE DATA, TYPE SCAN OR RUN

> WAIT

VALID FACTORS:

A = 3MS

B = 15MS

C = 25MS

A

> SET SCAN

"E" FORMAT(Y OR N) ? N

INPUT CHANNELS IN DESIRED ORDER

0,1,2,3,4,5

WHEN READY TO TAKE DATA, TYPE "SCAN" OR RUN

Figure 5 - DATA DEFINITION EXAMPLES

> SCAN

#	CH. 0	CH. 1	CH. 2	CH. 3	CH. 4	CH. 5
001	.0997	-25.98	-1.308	-.0574	.0355	.0006
002	.0997	-25.95	-1.306	-.0574	.0357	.0006
003	.0997	-26.05	-1.334	-.0572	.0366	.0006
004	.1118	-25.87	-1.276	-.0641	.0424	.0006
005	.1119	-25.89	-1.163	-.0639	.0426	.0006

> RUN

START POSIT = .1

STOP POSIT = -.02

INCREMENT = .03

#	CH. 0	CH. 1	CH. 2	CH. 3	CH. 4	CH. 5
006	.0995	-25.86	-1.261	-.0568	.0371	.0006
007	.0698	-25.56	-106.0	-.3309	-.1288	.0006
008	.0398	-25.56	80.72	.1612	.0127	.0006
009	.0097	-25.41	27.19	-.0509	-.0454	.0005
010	-.0202	-25.32	-22.10	.0410	.0162	.0006

>

Figure 6 - SCAN AND RUN EXAMPLES


```

*** RESET: ALL CHANNEL I/O IN "VOLTS" ***
> SCAN
01: CHANNELS NOT DEFINED
> SET SXAAXCAN
DELAY BETWEEN DATA POINTS = 15 MS (DEFAULT)
"E" FORMAT(Y OR N) ? N
INPUT CHANNELS IN DESIRED ORDER
0

WHEN READY TO TAKE DATA, TYPE  SCAN  OR  RUN

> RUN
START POSIT = 150051.150
STOP POSIT  = .05
INCREMENT   = .05
#          CH. 0

001      .1514
002      .0984
003      .0492

>

```

Figure 7 - IMPROPER INPUT EXAMPLE

> EDIT
THIS COMMAND IS USED TO INPUT
TEXT WHICH IS USED MANY TIMES
DURING A DATA LOGGING SESSION.

THE "FILE" COMMAND IS USED TO
RECALL THE TEXT.

> FILE

THIS COMMAND IS USED TO INPUT
TEXT WHICH IS USED MANY TIMES
DURING A DATA LOGGING SESSION.

THE "FILE" COMMAND IS USED TO
RECALL THE TEXT.

> FILE

THIS COMMAND IS USED TO INPUT
TEXT WHICH IS USED MANY TIMES
DURING A DATA LOGGING SESSION.

THE "FILE" COMMAND IS USED TO
RECALL THE TEXT.

> EDIT
THE RUBOITTIUT IS USDGTYTGTDEFUL

> FILE

THE RUBOUT IS USEFUL

> @
*** RESET: ALL CHANNEL I/O IN "VOLTS" ***
> EDIT
TTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTT

> EDIT
TTTTTT CNTRL-Z USED HERE
> FILE

TTTT CNTRL-Z USED HERETTTTTTTT
02: INVALID "FILE" TERMINATION

Figure 8 - EDIT AND FILE EXAMPLES


```

> INIT
  CHANNEL = 0
  INIT/VOLT = 10
  CHANNEL = 1
  INIT/VOLT = 999.225093
  CHANNEL = 2
  INIT/VOLT = -96.154
  CHANNEL =
> SET SCAN
  DELAY BETWEEN DATA POINTS = 15 MS (DEFAULT)
  "E" FORMAT(Y OR N) ? N
  INPUT CHANNELS IN DESIRED ORDER
  012

  WHEN READY TO TAKE DATA, TYPE SCAN OR RUN
>
***** WIND OFF TAKES
> SCAN

#      CH. 0      CH. 1      CH. 2

001      .0061      .0115      -.2714      WIND OFF ZERO
> RUN
START POSIT = -6
STOP POSIT  = 14
INCREMENT   = 1
#      CH. 0      CH. 1      CH. 2

002      -6.015      .0135      -.7822
003      -4.972      .0123      -.2274
004      -3.986      .0138      -.3127
005      -2.996      .0109      -.2283
006      -2.000      .0151      -.2036
007      -.9803      .0154      -.2384
008      .0061      .0112      -.3301
009      1.031      .0153      -.2421
010      2.016      .0160      -.2613
011      3.035      .0184      -.3035
012      4.022      .0212      -.2870
013      5.012      .0190      -.3017
014      6.017      .0184      -.2934
015      7.024      .0193      -.3145
016      8.013      .0221      -.1953
017      9.000      .0237      -.2366
018      10.02      .0239      -.2549
019      11.01      .0237      -.1678
020      12.03      .0285      -.1586
021      13.03      .0210      -.0953
022      14.02      .0217      -.0586

```

Figure 9 - WIND-TUNNEL TARE DATA

***** DATA RUN AT U = 40 PSF 11 JUNE 1977
 > SCAN

#	CH. 0	CH. 1	CH. 2
026	.0061	.0297	-.0586
027	.0061	.0295	-.0586
028	.0061	.0293	-.0586

> RUN

START POSIT = -6
 STOP POSIT = 14
 INCREMENT = 1

#	CH. 0	CH. 1	CH. 2
029	-6.040	40.17	-29.05
030	-4.992	39.69	-23.60
031	-3.997	39.62	-18.24
032	-2.989	39.60	-13.61
033	-1.997	40.02	-8.854
034	-.9773	39.79	-4.446
035	.0061	39.87	.5072
036	1.032	40.22	5.316
037	2.019	40.48	10.44
038	3.036	40.52	14.59
039	4.024	41.10	19.53
040	5.041	40.61	24.65
041	6.008	40.53	29.07
042	7.025	41.05	34.11
043	8.013	40.23	37.71
044	9.003	40.17	41.27
045	10.02	40.71	45.30
046	11.01	39.85	46.12
047	12.03	40.32	43.28
048	13.03	39.71	47.69
049	14.02	39.37	48.12

> SCAN

#	CH. 0	CH. 1	CH. 2
050	.0061	.0568	-.0586

WIND OFF ZERO

> LUMP

10.00000
 9.225093
 -96.15401
 1.000000
 1.000000
 1.000000
 1.000000
 1.000000

Figure 10 - WIND-TUNNEL DATA RUN




Figure 11 - PLOT OF WIND-TUNNEL DATA

> FILE

THIS IS AN EXAMPLE OF DECIMAL
AND EXPONENTIAL FORMAT.

> SET SCAN

DELAY BETWEEN DATA POINTS = 15 MS (DEFAULT)

"E" FORMAT(Y OR N) ? N

INPUT CHANNELS IN DESIRED ORDER

012

WHEN READY TO TAKE DATA, TYPE "SCAN" OR RUN

> SCAN

#	CH. 0	CH. 1	CH. 2
---	-------	-------	-------

001	-5.036	-.0413	-.0019
-----	--------	--------	--------

002	-5.036	-.0413	-.0018
-----	--------	--------	--------

>

> SET SCAN

DELAY BETWEEN DATA POINTS = 15 MS (DEFAULT)

"E" FORMAT(Y OR N) ? Y

INPUT CHANNELS IN DESIRED ORDER

> SCAN

#	CH. 0	CH. 1	CH. 2
---	-------	-------	-------

001	-5.036	-4.160E-02	-3.110E-03
-----	--------	------------	------------

002	-5.035	-4.138E-02	-2.680E-03
-----	--------	------------	------------

>

Figure 12 - EXPONENTIAL FORMAT EXAMPLES

IV. WIND TUNNEL APPLICATION


The ADL system was constructed in order to facilitate data acquisition and documentation from the 3.5 x 5.0 foot subsonic wind-tunnel located in the Department of Aeronautics at the Naval Postgraduate School. Logging data by hand from the tunnel balance is time consuming, error inducing and produces somewhat biased and scattered results. Other related problems are:

1. Personnel communications in a noisy environment.
2. Meter reading while the quantity to be measured is subjected to random perturbations.
3. Tunnel heating due to long run times.
4. Time consuming AOA setting.



The ADL effectively eliminated all the above problems and in addition it proved to be versatile enough to be used as a data logger with other equipment. Figure 13 is a picture of the ADL installation. It fits compactly into a roll-around cabinet and requires only a standard 20 mA current loop, 110 baud I/O device (e.g., a teletype), and patch cords to connect it to the voltage sources it is to monitor. Five variable-gain, linear amplifier cards are included to provide low level signal buffering. Voltage sources can be connected to the ADL directly or patched through an amplifier, as long as the input excursions do not exceed -10V to +10V.

The feedback control function is implemented via two output lines - one labeled UP and the other labeled DOWN.

Each line carries an independent logic level voltage which is used to actuate a relay. The two relays in turn are used to control the direction of a motor. The desired feedback quantity (in this case position) is input to channel 0 which closes the digital control loop. Figure 14 is a detailed schematic of the AOA control as used in the wind tunnel system. To date, the ADL was used to calibrate the wind tunnel balance and the dynamic pressure transducer [1].



- A - Amplifier cards and A/D modules
- B - 805 Microprocessor



- C - 2K PROM memory
- D - CPU
- E - A/D, sample-and-hold and multiplexer
- F - Linear amplifier





Figure 13 - PHOTOS OF ADL COMPONENTS




Figure 14 - ANGLE-OF-ATTACK FEEDBACK LOOP

V. SOFTWARE DESIGN

The assembled program listing for the ADL is presented in this chapter along with flowcharts for the most important routines. Throughout the following paragraphs, frequent reference is made to the 'position' of an external device. 'Position' is used for illustration; speed, angle or many other attributes of the state of an external device can be used as a feedback parameter.

Figure 15 shows the averaging process used in the filter routine. A running sum is taken at 128 data points. This sum is then divided by 128, converted back to binary and stored as a two byte quantity in registers D and E. The binary representation of the current desired position of the external device is recalled from memory and stored in registers B and C. Upon exit from the routine, the registers are set up to compare the actual and desired positions in order to determine in which direction to move the external device. The 'UP' driver is next shown. It makes use of the previous subroutine to determine when the desired position has been reached. The position correction routine in fig. 17 determines if the position arrived at by the UP or DOWN routines has met predefined error criteria. There are also routines for the DOWN direction that are identical to figs. 16 and 17 (except for the direction of movement). The MOVE routine is in fig 18; it provides the logic necessary to properly call the UP and DOWN routines. Figures 19 and 20 are flowcharts of the RUN routine. RUN provides the automatic control function of the ADL by calling SCAN and MOVE at external device positions defined by the user.




Figure 15 - NOISE AND GLITCH FILTER LOGIC




Figure 16 - 'UP' RELAY DRIVER LOGIC




Figure 17 - OVERTHOOT/UNDERSHOOT CORRECTION LOGIC




Figure 18 - EXTERNAL DEVICE CONTROL LOGIC




Figure 19 - RUN ROUTINE LOGIC (PART 1)




Figure 20 - RUN ROUTINE LOGIC (PART 2)

The following software was developed in small independent subroutines. This was done so that future revisions to logic could be accomplished with a minimum of redesign. For example, if a line printer is added to the system, all references to subroutine C0 (console output) are changed so that the new routine can be called. The EQUATE tables at the start of each section of software are modified to reflect the address of the new routine, and the software is then reassembled. Similar procedures can be followed to alter I/O assignment, add new routines, etc. Memory requirements for the ADL software are as follows:

1. Pages 00H to 0FH, ROM
2. Pages 20H to 27H, ROM
3. Pages 10H to 1FH, RAM

This program was compiled on the INTELLEC 8 microprocessor development system for the 8008 U-P.


```

;
; UTILITY SUBROUTINES. THIS SECTION CONTAINS
; SUBROUTINES COMMON TO ALL MAJOR SECTIONS
; OF SOFTWARE.
;

```

```

0000          ORG 0

;
032F      INIT      EQU 032FH      ;F.P. INITIALIZATION
036E      LOD       EQU 036EH      ;LOAD F.P. ACCUM
033E      STR       EQU 033EH      ;PLACE CONTENTS OF
                                   ;F.P. ACCUM INTO
                                   ;MEMORY
064B      INN       EQU 064BH      ;CHANGE BCD DATA TO
                                   ;F.P. AND LOAD ACCUM.
070F      OUU       EQU 070FH      ;CHANGE F.P. NUMBER
                                   ;TO BCD DATA STRING
03D7      AD        EQU 03D7H      ;F.P. ADDITION
03D4      SB        EQU 03D4H      ;F.P. SUBTRACTION
038C      MUL       EQU 038CH      ;F.P. MULTIPLY
03B4      DIV       EQU 03B4H      ;F.P. DIVIDE
0001      ABT       EQU 01H        ;COMMAND EXIT
                                   ; (CONTROL A)
000D      SCHAR     EQU 0DH        ;STOP CHAR
001A      SUBT      EQU 1AH        ;CHARACTER SUBSTITUTION
                                   ; (CONTROL Z)
10A0      STACK     EQU 10A0H      ;VARIABLE STORAGE
10FD      JUMP      EQU 10FDH      ;VECTORED JUMP
02B7      TEST      EQU 02B7H      ;LIGHT TEST
02CA      BLANK     EQU 02CAH      ;DISPL BLANKING
1040      DOPND     EQU 1040H      ;DECIMAL OPERAND BUFFER
1058      STORE     EQU 1058H      ;TEMP BUFFER
1070      RESLT     EQU 1070H      ;DECIMAL ANS BUFFER
0F00      TABLE    EQU 0F00H      ;TABLE OF VALID COMMAND
                                   ;CODES AND VECTORS.
                                   ;OPERATIONS
10C0      SCANB     EQU 10C0H      ;BUFFER CONTAINING
                                   ;CHANNEL SCAN INFO.
1080      CFBUF     EQU 1080H      ;CONVERSION FACTORS
007F      RBOUT     EQU 7FH        ;RUBOUT CHAR
0E8E      MTEST     EQU 0E8EH      ;RAM MEMORY TEST
;
; MESSAGES USED BY THIS SECTION ARE ANNOTATED
; AT THE END OF THE PROGRAM LISTING
;
2600      READY     EQU 2600H
2603      LERR      EQU 2603H
2648      LBOOT     EQU 2648H
;
0000 CO      DB 0COH      ;FIRST INSTR = NOP
0001 06FF    QUIET:  MVI A,0FFH  ;RESET TTY BREAK
0003 51      OUT 8
0004 46B702  CALL TEST      ;CHECK DISPLAY
0007 464500  WAIT1:  CALL CI   ;WAIT FOR OPERATOR
000A 468EOE  CALL MTEST     ;CHECK RAM

```



```

000D 46CA02      CALL BLANK      ;CHECK DISPLAY
0010 462F03      BOOT:    CALL INIT      ;INITIALIZE MATH PAC
                                           ;AND DEFAULT VALUES.

0013 2E10367D    LXI H,RESLT+13
0017 3E0D        MVI M,SCHAR
0019 2E1036C0    LXI H,SCANB
001D 3E2A        MVI M,'*'      ;INVALID SCAN FLAG
001F 2E1036B0    LXI H,STACK+16  ;"WAIT" FLAG STORAGE
0023 3E2A        MVI M,'*'      ;15MS DEFAULT FLAG
0025 2E103680    LXI H,CFBUF     ;FILL CONVERSION FACTOR
                                           ;BUFFER WITH 1.0

0029 0E20        MVI B,32
002B 3E00        LOOP1: MVI M,0
002D 30          INR L
002E 09          DCR B
002F 482B00      JNZ LOOP1
0032 2E103680    LXI H,CFBUF
0036 0E08        MVI B,8
0038 3E81        LOOP2: MVI M,81H      ;1.0=81000000H
003A 0604        MVI A,4
003C 86          ADD L
003D F0          MOV L,A
003E 09          DCR B
003F 483800      JNZ LOOP2
0042 448D00      JMP MON          ;START

;
; 'CI' CONSOLE INPUT ROUTINE
; INPUT: NO RESTRICTIONS
; REGISTERS: A,B,C,D
; OUTPUT: A,B ASCII
;          C,D = 0
0045 49          CI:    IN 4      ;GET START BIT
0046 1A          RAR
0047 604500      JC CI
004A 466A00      START: CALL HALF      ;1/2 DELAY
004D 1608        MVI C,8          ;BIT COUNT
004F 466500      RX:    CALL DELAY    ;CENTER OF NEXT BIT
0052 49          IN 4
0053 1A          RAR              ;ROT INTO CARRY
0054 C1          MOV A,B          ;GET BUILD-UP WORD
0055 1A          RAR
0056 C8          MOV B,A          ;STORE
0057 11          DCR C            ;C=C-1
0058 484F00      JNZ RX          ;CHECK FOR LAST BIT
005B 247F        ANI 7FH         ;MASK OFF PARITY
005D C8          MOV B,A
005E 466500      CALL DELAY
0061 466500      CALL DELAY
0064 07          RET

;
; 'DELAY' TTY DELAY LOOP
; DELAY PARAMETER IN 'D'
; PROVIDES 9MS DELAY.
0065 1EC5        DELAY: MVI D,0C5H      ;1 BIT TIME
0067 446C00      JMP TIME

```



```

006A 1E62      HALF:   MVI D,062H      ;1/2 BIT TIME
006C 19        TIME:   DCR D
006D 486C00    JNZ TIME
0070 07        RET

;
; 'CRLF' OUTPUTS A CARRIAGE RET AND
; LINE FEED.
; INPUT: NO RESTRICTIONS
; REGISTERS: A,B,C,D
; OUTPUT: A=FFH,B=0AH;C,D=0
0071 0E0D      CRLF:   MVI B,0DH      ;CR
0073 467C00    CALL CO
0076 0E0A      MVI B,0AH      ;LF
0078 467C00    CALL CO
007B 07        RET

;
; 'CO' CONSOLE OUTPUT ROUTINE
; INPUT: WORD IS 7 BIT ASCII
;         STORED IN B
; REGISTERS: A,B,C,D
; OUTPUT: A=FFH, B IS SAVED, C,D = 0
;
007C C1        CO:     MOV A,B      ;FETCH WORD
007D B0        ORA A      ;CLEAR CARRY
007E 160B      MVI C,11      ;BIT COUNTER
0080 12        RAL      ;START BIT
0081 51        SEND:   OUT 8      ;TX TO TTY
0082 466500    CALL DELAY      ;WAIT 1 BIT TIME
0085 1A        RAR      ;POSITION NEXT BIT
0086 3CFF      CPI 0FFH      ;SET STOP BIT
0088 11        DCR C      ;C=C-1
0089 488100    JNZ SEND      ;SEND IF NOT DONE
008C 07        RET

;
; MONITOR ENTRY POINT AFTER POWER ON OR RESET.
;
008D 467100    MON:     CALL CRLF      ;RESET CARRIAGE
0090 2E263648  LXI H,LBOOT      ;START INFORMATION
0094 46E800    CALL LIST
0097 467100    CNTRL:   CALL CRLF
009A 2E263600  LXI H,READY      ;ACK
009E 46E800    CALL LIST

;
; GET COMMAND WORD AND FORM JUMP VECTOR
;
00A1 46F800    RECOG:   CALL GET
00A4 0E00      MVI B,0      ;INIT CHECK SUM
00A6 2E103640  LXI H,DOPND      ;POINT TO INPUT BUFF
00AA C7        RLOOP:   MOV A,M      ;FETCH CHARACTER
00AB 3C0D      CPI SCHAR      ;IF DONE SEARCH
00AD 68B600    JZ SRCH      ; LOOK-UP TABLE
00B0 81        ADD B      ;ELSE BUILD CHECK SUM
00B1 C8        MOV B,A      ;STORE CK SUM
00B2 30        INR L

```



```

00B3 44AA00      JMP RLOOP
00B6 2E0F3600 SRCH: LXI H,TABLE      ;POINT TO LOOK-UP
00BA C7          SRCHL: MOV A,M      ;
00BB 3C00        CPI 0              ;VALIDITY CHECK
00BD 68DE00      JZ ERR
00C0 B9          CMP B              ;COMPARE CHECK SUM WITH
00C1 68CA00      JZ VCTR            ; TABLE. IF TRUE, JMP.
00C4 30          INR L              ;ELSE GET NEXT
00C5 30          INR L
00C6 30          INR L
00C7 44BA00      JMP SRCHL
00CA 30          VCTR: INR L          ;POINT TO LOW ADD
00CB CF          MOV B,M            ;SAVE
00CC 30          INR L              ;POINT TO HI ADD
00CD D7          MOV C,M            ;SAVE
00CE 2E1036FD    LXI H,JUMP         ;POINT TO JUMP LCN
00D2 3E44        MVI M, 44H
00D4 30          INR L              ;LOAD VECTOR
00D5 F9          MOV M,B
00D6 30          INR L
00D7 FA          MOV M,C
00D8 467100      CALL CRLF
00DB 44FD10      EXEC: JMP JUMP      ;EXECUTE
00DE 2E263603 ERR: LXI H,LERR       ;ERROR MSG OUT
00E2 46E800      CALL LIST
00E5 449700      JMP CNTRL          ;TRY AGAIN

;
; THIS ROUTINE IS USED TO OUTPUT
; STRINGS OF ALFA-NUM CHARACTERS
00E8 CF          LIST: MOV B,M        ;OUT REGISTER
00E9 C7          MOV A,M
00EA 3C0D        CPI SCHAR          ;IF DONE RET
00EC 2B          RZ
00ED 467C00      CALL CO            ;PRINT CHAR
00F0 30          INR L              ;POINT TO NEXT
00F1 48E800      JNZ LIST           ;CHECK FOR PAGE WRAP
00F4 28          INR H
00F5 44E800      JMP LIST           ;GET NEXT

;
; 'GET' IS USED TO LOAD NUM DATA
; INTO DOPND OR LABELS INTO
; ANY DESIRED BUFFER. INSERTS
; 'CR' AS THE STOP CHAR.
; BUFFER CANNOT START AT XX00.
; DOES NOT ECHO A CARRIAGE RET.
; 'RUBOUT' ERASES PREVIOUSLY ENTERED
; CHARACTERS IN SUCCESSION.
; 'CONTROL Z' IS USED TO DISPLAY THE
; CONTENTS OF THE NEXT MEMORY LOCATION.
; RETURNS WITH LOW POINTER AT SCHAR.
;
00F8 2E103640 GET:  LXI H,DOPND      ;DEFAULT BUFFER
00FC E6          GETD: MOV E,L        ;DESIRED BUFFER ENTRY

```



```

00FD 464500      CNTU:  CALL CI          ;SAVE LO POINTER
0100 3C7F        ;TTY INPUT
0102 682C01      ;IF RUBOUT
0105 3C01        ;THEN ERASE
0107 689700      ;COMMAND EXIT
010A 3C1A        ;DISPLAY NEXT CELL
                  ;TO ALLOW FOR
                  ;SUBSTITUTION.

010C 681E01      JZ CNTU4
010F 3C0D        CPI SCHAR          ;IF DONE RETURN
0111 481601      JNZ CNTU1
0114 F8          MOV M,A           ;STORE STOP CHAR
0115 07          RET
0116 467C00      CNTU1: CALL CO      ;ECHO OUT
0119 F9          MOV M,B           ;LOAD INPUT
011A 30          INR L             ;POINT TO NEXT CELL
011B 44FD00      JMP CNTU          ;GET NEXT
011E C7          CNTU4: MOV A,M     ;CHECK FOR EOL
011F 3C0D        CPI SCHAR
0121 6A7600      CZ CRLF+5         ;IF TRUE ,LINE-FEED
0124 CF          MOV B,M           ;DISPLAY CONTENTS OF
                  ;CURRENT CELL

0125 467C00      CALL CO
0128 30          INR L             ;POINT TO NEXT CELL
0129 44FD00      JMP CNTU          ;GET NEXT

;
; 'ERASE' IS USED TO RUB OUT AN
; INCORRECTLY ENTERED CHAR.
012C 31          ERASE: DCR L       ;POINT TO LAST INPUT
012D C6          MOV A,L           ;CHECK TO ENSURE
012E BC          CMP E             ; INPUT BUFER WILL
012F 403301      JNC ECHO          ; NOT UNDERFLOW
0132 30          INR L             ; RESTORE LO POINT
0133 CF          ECHO:  MOV B,M     ;FETCH BAD CHAR
0134 467C00      CALL CO           ;REPEAT CHAR
0137 44FD00      JMP CNTU

;
; 'STRIP' CHANGES ASCII INTO
; SPECIAL BCD USED BY THE
; FLOATING POINT ROUTINE
; H,L MUST POINT TO BUFFER
;
013A C7          STRIP: MOV A,M     ;FETCH
013B 3C0D        CPI SCHAR        ;IF DONE RET
013D 2B          RZ
013E 1430        SUI 30H          ;BCD CONVERSION
0140 F8          MOV M,A          ;STORE BCD
0141 30          INR L            ;POINT
0142 443A01      JMP STRIP        ;GET NEXT

;
; 'DISPY' CONVERTS SPECIAL BCD
; FROM THE FLOATING POINT ROUTINE
; TO ASCII.

```



```

0145 2E103670 DISPY: LXI H,RESLT      ;POINT TO BUFF
0149 C7         DISPL: MOV A,M         ;FETCH
014A 3C0D       CPI SCHAR             ;IF DONE RET
014C 2B         RZ
014D 0430       ADI 30H                ;BCD TO ASCII
014F F8         MOV M,A               ;STORE
0150 30         INR L
0151 444901     JMP DISPL

;
; 'BINFP' CHANGES RAW BINARY DATA
; TO FLOATING POINT
0154 C7         BINFP: MOV A,M         ;FETCH HI BYTE
0155 C8         MOV B,A
0156 30         INR L
0157 D7         MOV C,M               ;FETCH LO BYTE
0158 A0         ANA A                 ;CLEAR CARRY
0159 2611       MVI E,17              ;RESET COUNT
015B 706D01     SHIFT: JM EXIT        ;IF NEGATIVE
;DATA IS NORM
;SAVE HI
;E=E-1
015E C8         MOV B,A
015F 21         DCR E
0160 688201     JZ DZER               ;IS 0
0163 C2         MOV A,C               ;LOAD LO BYTE
0164 A0         ANA A                 ;CLEAR CARRY
0165 12         RAL                   ;TWO BYTE SHIFT
0166 D0         MOV C,A               ;TO THE LEFT
0167 C1         MOV A,B
0168 12         RAL
0169 A0         ANA A                 ;SET CNTRL BITS
016A 445B01     JMP SHIFT              ;NEXT SHIFT
016D 247F       EXIT: ANI 7FH          ;POS NUM MASK
016F 2E103659   LXI H,STORE+1
0173 F8         MOV M,A               ;MS FP BYTE
0174 30         INR L
0175 FA         MOV M,C               ;NEXT FP BYTE
0176 30         INR L
0177 3E00       MVI M,0               ;LS FP BYTE
0179 067F       MVI A,7FH             ;EXP ADJUST
017B 84         ADD E                 ;BIAS-#SHIFTS
017C 2E103658   LXI H,STORE
0180 F8         MOV M,A               ;STORE EXP
0181 07         RET                   ;NORMAL EXIT
0182 2E103658   DZER: LXI H,STORE     ;DATA=0
0186 3E00       MVI M,0
0188 07         RET                   ;0 EXIT

;
; 'FPBIN' CHANGES FLOATING POINT
; TO BINARY. HL MUST POINT TO HIGH BYTE
; OF FP DATA UPON ENTRY
; RAW RESULT IS IN DE.
0189 C7         FPBIN: MOV A,M
018A 1480       SUI 80H                ;STRIP EXCESS 80H
018C C8         MOV B,A               ;SAVE
018D 0610       MVI A,16              ;2 BYTE BIAS

```


018F 91		SUB B		;COMPUTE # SHIFTS
0190 C8		MOV B,A		;SAVE
0191 30		INR L		
0192 C7		MOV A,M		
0193 3480		ORI 80H		;FORM MSBYTE
0195 D8		MOV D,A		;SAVE IT
0196 30		INR L		
0197 E7		MOV E,M		;GET LSBYTE
0198 C3	CNTU3:	MOV A,D		;RESTORE
0199 B0		ORA A		;SHIFT 2 BYTES
019A 1A		RAR		
019B D8		MOV D,A		
019C C4		MOV A,E		
019D 1A		RAR		
019E E0		MOV E,A		
019F 09		DCR B		;CHECK COUNTER
01A0 489801		JNZ CNTU3		
01A3 07		RET		
0000	END			


```

;
; DISPLAY LIGHT ROUTINES
; USED TO OUTPUT VOLTAGE DATA TO THE
; DISPLAY LITES. DATA IS OUTPUT IN
; 4 SIGNIFICANT FIGURES. THIS SECTION
; ALSO CONTAINS THE LITE TEST AND LITE
; BLANK FUNCTIONS WHICH ARE CALLED AS
; PART OF SYSTEM BOOT.
;
0000          ORG 01COH
;
; EQUATES NOT ANNOTATED IN THIS SECTION
; CAN BE FOUND IN PREVIOUS SECTIONS
;
1070  RESULT    EQU 1070H      ;DECIMAL RESULT
00FD  MINUS     EQU 0FDH       ;'-'- 30H
00FE  DECPT     EQU 0FEH       ;'. '- 30H
00F0  SPACE     EQU 0F0H       ;' ' - 30H
106C  SSTAT     EQU 106CH      ;SIGN STATUS STORAGE
006C  STAT      EQU 06CH       ;SSTAT POINTER
0030  PLO       EQU 030H      ;POS SIGN/LATCH OFF
000A  LT        EQU 0AH       ;LITE TEST COMMAND
00F0  DOM       EQU 0F0H      ;DEC POINT OFF MASK
00E0  DPOL      EQU 0EOH      ;DP IN LITE #0
00D0  DP1L      EQU 0DOH      ;DP IN LITE #1
00B0  DP2L      EQU 0BOH      ;DP IN LITE #2
0070  DP3L      EQU 070H      ;DP IN LITE #3
;
; OUTPUT SIGN AND STORE AS A STATUS WORD
;
01C0 2E103670  DISPL:  LXI H,RESULT    ;POINT TO RESULT
01C4 C7        MOV A,M                ;FETCH SIGN
01C5 366C      MVI L,STAT
01C7 3CFD      CPI MINUS              ;IF - JUMP
01C9 68D201    JZ SETM
01CC 0610      SETP:  MVI A,10H        ;+ AND DISABLE
01CE 55        OUT 2+8
01CF 44D501    JMP CNTU
01D2 0630      SETM:  MVI A,30H        ;- AND DISABLE
01D4 55        OUT 2+8
01D5 F8        CNTU:  MOV M,A          ;STORE STATUS
;
; FETCH DIGITS FROM RESULT BUFFER,
; AND OUTPUT TO DISPLAY LIGHTS
;
01D6 3671      MVI L,71H              ;GET FIRST DIGIT
01D8 C7        MOV A,M
01D9 3CFE      CPI DECPT
01DB 685802    JZ ZERO                ;IF DP, ADD LEADING 0'S
01DE DF        MOV D,M                ;SAVE FIRST DIGIT
01DF 30        INR L
01E0 C7        MOV A,M                ;FETCH NEXT
01E1 3CFE      CPI DECPT
01E3 682602    JZ LZERO              ;IF DP, JUMP

```



```

01E6 0E00          MVI B,0          ;ELSE OUTPUT FIRST DIGIT
01E8 460902        CALL NODP
01EB 3CFE          CPI DECPT        ;CHECK 2ND DIGIT
01ED 687F02        JZ DP1
01F0 0E01          MVI B,1
01F2 460902        CALL NODP
01F5 3CFE          CPI DECPT
01F7 688A02        JZ DP2
01FA 0E02          MVI B,2
01FC 460902        CALL NODP
01FF 3CFE          CPI DECPT
0201 689502        JZ DP3
0204 0E03          MVI B,3
0206 440902        JMP NODP          ;EXIT

```

```

;
; OUTPUT A DIGIT WITH NO DP.
;

```

```

0209 06F0          NODP:  MVI A,DOM
020B B3            ORA D          ;ATTACH DATA
020C 461302        CALL LITE      ;OUT
020F DF            MOV D,M        ;SAVE DIGIT
0210 30            INR L
0211 C7            MOV A,M        ;FETCH NEXT
0212 07            RET

```

```

;
; OUTPUT AND LATCH
; REGISTER B CONTAINS MUX ADD OF LITE
;

```

```

0213 E6            LITE:  MOV E,L          ;SAVE POINT
0214 2CFF          XRI OFFH
0216 57            OUT 8+3          ;DATA OUT
0217 2E10366C      LXI H,SSTAT      ;GET STATUS
021B C7            MOV A,M
021C B1            ORA B          ;ATTACH MUX INFO
021D 55            OUT 8+2          ;MUX AND SIGN OUT
021E 2C10          XRI 10H
0220 55            OUT 8+2          ;SET LATCH
0221 2C10          XRI 10H
0223 55            OUT 8+2          ;LATCH OFF
0224 F4            MOV L,E          ;RESTORE
0225 07            RET

```

```

;
; OUTPUT LEADING ZEROS IF NEEDED
; TO CHANGE FROM SCIENTIFIC NOTATION
; TO FIXED POINT.
;

```

```

0226 367C          LZERO: MVI L,07CH
0228 C7            MOV A,M          ;GET EXP
0229 3CF0          CPI SPACE
022B 483302        JNZ LZERI        ;CONTINUE IF NOT ' '
022E 3672          MVI L,072H      ;RESTORE
0230 445C02        JMP DPO
0233 DF            LZERI:  MOV D,M
0234 3671          MVI L,71H

```



```

0236 0E00          MVI B,0
0238 06E0          MVI A,DPOL          ;0 + 1 DP
023A 461302        CALL LITE
023D 08            INR B
023E 06F0          MVI A,DOM          ;0 + NO DP
0240 461302        CALL LITE
0243 19            DCR D
0244 19            DCR D
0245 689D02        JZ OUTZ2
0248 08            INR B
0249 06F0          MVI A,DOM
024B 461302        CALL LITE
024E 19            DCR D
024F 687702        JZ OUTZ1
0252 08            INR B
0253 06F0          MVI A,DOM
0255 441302        JMP LITE          ;EXIT
0258 3671          ZERO: MVI L,71H
025A 1E00          MVI D,0          ;DATA

;
; INDIVIDUAL DIGIT OUTPUTS
;
025C 0E00          DPO:  MVI B,0
025E 06E0          MVI A,DPOL
0260 B3            ORA D          ;ATTACH DATA
0261 461302        CALL LITE
0264 30            OUT3:  INR L
0265 C7            MOV A,M
0266 34F0          ORI DOM          ;ATTACH NO DP
0268 0E01          MVI B,1
026A 461302        CALL LITE
026D 30            OUT2:  INR L
026E C7            MOV A,M
026F 34F0          ORI DOM
0271 0E02          MVI B,2
0273 461302        CALL LITE
0276 30            OUT1:  INR L
0277 C7            OUTZ1: MOV A,M
0278 34F0          ORI DOM
027A 0E03          MVI B,3
027C 441302        JMP LITE          ;EXIT
027F 0E01          DP1:  MVI B,1
0281 06D0          MVI A,DP1L
0283 B3            ORA D          ;ATTACH DATA
0284 461302        CALL LITE
0287 446D02        JMP OUT2
028A 0E02          DP2:  MVI B,2
028C 06B0          MVI A,DP2L
028E B3            ORA D
028F 461302        CALL LITE
0292 447602        JMP OUT1
0295 0E03          DP3:  MVI B,3
0297 0670          MVI A,DP3L
0299 B3            ORA D

```



```

029A 441302      JMP LITE          ;EXIT
029D C7          OUTZ2: MOV A,M
029E 34F0        ORI DOM
02A0 0E02        MVI B,2
02A2 461302      CALL LITE
02A5 30          INR L
02A6 447602      JMP OUT1

;
; OUTPUT CHANNEL NUMBERS
;
02A9 0E07        CLITE: MVI B,7      ;LITE ADDRESS
02AB 34F0        ORI DOM            ;ATTACH NO D.P.
02AD 461302      CALL LITE          ;OUTPUT CHANNEL #
02B0 0E06        MVI B,6
02B2 06F0        MVI A,DOM          ;OUTPUT '0'
02B4 441302      JMP LITE

;
; LIGHT TEST AND BLANK
; CALLED DURING POWER-UP OR RESET
; ACCUM CONTAINS THE DISPLAY DATA.
; REGISTER B CONTAINS THE MUX LITE NUMBER
;
02B7 0E07        TEST:  MVI B,7
02B9 2E10366C    LXI H,SSTAT
02BD 3E10        MVI M,10H
02BF 1E0A        MVI D,LT
02C1 C3          TESTL: MOV A,D
02C2 461302      CALL LITE
02C5 09          DCR B
02C6 50C102      JP TESTL
02C9 07          RET
02CA 0E07        BLANK: MVI B,7
02CC 2E10366C    LXI H,SSTAT
02D0 3E30        M,PLO
02D2 1EFF        MVI D,OFFH        ;TURN OFF LITES
02D4 44C102      JMP TESTL
0000            END

```


PROGRAM SPACE 0300H TO 07FFH
IS USED FOR THE FLOATING POINT
PACKAGE. APPENDIX C PRESENTS
EXCERPTS FROM THE INTEL
USERS LIBRARY.

END


```

;
; A/D SAMPLE AND HOLD
; THIS SECTION CONTAINS THE CODE TO PROPERLY
; DRIVE THE 'DATEL' (SEE TEXT) DATA
; ACQUISITION MODULES. ALSO INCLUDED IS THE
; "READ" ROUTINE WHICH GENERATES THE
; VOLTMETER OUTPUT ON THE DISPLAY LIGHTS.
;
0000          ORG 0800H
;
; EQUATES NOT ANNOTATED CAN BE FOUND IN
; PREVIOUS SECTIONS.
;
0009  CMD      EQU 9          ;OUTPUT PORT 1
0007  LBYTE    EQU 7          ;INPUT PORT 1
0005  MBYTE    EQU 5          ;INPUT PORT 2
106D  RAW      EQU 106DH      ;RAW DATA INPUT BUFFER
106F  MUXCH    EQU 106FH      ;DEFAULT MUX CHANNEL STORE
000D  SCHAR    EQU 0DH        ;STOP CHAR
00E8  LIST     EQU 00E8H      ;OUTPUT 1 LINE
                                ;OF TEXT
0071  CRLF     EQU 0071H      ;OUTPUT CARRAGE RET-
                                ;LINE FEED
00F8  GET      EQU 00F8H      ;INPUT DATA FROM
                                ;OPERATOR
013A  STRIP    EQU 013AH      ;BCD←ASCII
0154  BINFP    EQU 0154H      ;F.P.←BIN
01C0  DISPL    EQU 01C0H      ;OUTPUT DATA TO
                                ;LIGHT DISPLAY
02A9  CLITE    EQU 02A9H      ;OUTPUT CHAN # IN
                                ;'A' TO DISPAY LIGHTS
OFF4  I2       EQU OFF4H      ; 10.0
OFF8  I3       EQU OFF8H      ; 819.15
OFFC  I4       EQU OFFCH      ; 8191.5
1040  DOPND    EQU 1040H
1058  STORE    EQU 1058H
1070  RESLT    EQU 1070H
070F  OUU      EQU 070FH
036E  LOD      EQU 036EH
033E  STR      EQU 033EH
03D7  AD       EQU 03D7H
03D4  SB       EQU 03D4H
038C  MUL      EQU 038CH
03B4  DIV      EQU 03B4H
;
; MESSAGES
2672  LREAD    EQU 2672H
;
;
; 'SHOLD' EXECUTES ONE SAMPLE AND HOLD
; CYCLE, AND INPUTS A DOUBLE BYTE
; OF RAW DATA.
; INPUT: ACUM CONTAINS MUX CHANNEL
;        H,L POINT TO LSBYTE STORAGE

```



```

; REGISTERS: A,L
; OUTPUT: 'A' DESTROYED, L=L-1
;
0800 3410 SHOLD: ORI 10H ;RESET A/D MODULE
0802 53 OUT CMD
0803 3418 ORI 18H ;SAMPLE
0805 53 OUT CMD
0806 2C10 XRI 10H ;HOLD
0808 53 OUT CMD
0809 4B READ1: IN MBYTE
080A 2440 ANI 40H ;CHECK FOR END OF CONVERT
080C 480908 JNZ READ1
080F 4F IN LBYTE ;INPUT RAW DATA
0810 2CFF XRI 0FFH
0812 F8 MOV M,A
0813 31 DCR L
0814 4B IN MBYTE
0815 243F ANI 3FH
0817 2C3F XRI 3FH
0819 F8 MOV M,A
081A 07 RET

;
; "RVI" CHANGES RAW FLOATING POINT DATA
; TO VOLTAGE UNITS PROPORTIONAL
; TO THE RAW DATA FROM THE A/D. "VRI"
; PERFORMS THE INVERSE OPERATION.
;
081B 2E103658 RVI: LXI H,STORE
081F 466E03 CALL LOD ;A←M
0822 2E0F36F8 LXI H,I3
0826 46B403 CALL DIV ;A←A/819.15
0829 2E0F36F4 LXI H,I2
082D 46D403 CALL SB ;A←A-10.0
0830 07 RET
0831 2E103658 VRI: LXI H,STORE
0835 466E03 CALL LOD ;A←M
0838 2E0F36F8 LXI H,I3
083C 468C03 CALL MUL ;A←A*819.15
083F 2E0F36FC LXI H,I4
0843 46D703 CALL AD ;A←A+8191.5
0846 07 RET

;
; 'READ' IS USED FOR CALIBRATION OF
; ANY DESIRED CHANNEL. OUTPUT IS ON THE
; DIGITAL DISPLAY IN VOLTAGE UNITS.
;
0847 2E263672 READ: LXI H,LREAD ;PROMPT
084B 46E800 CALL LIST
084E 46F800 CALL GET ;INPUT CH. NO.
0851 467100 CALL CRLF
0854 2E103640 LXI H,DOPND
0858 463A01 CALL STRIP ;BCD←ASCII
085B 2E103640 LXI H,DOPND
085F C7 MOV A,M

```


0860 2E10366F	LXI H,MUXCH	;STORE CH. NO.
0864 F8	MOV M,A	
0865 46A902	CALL CLITE	;DISPLAY CH. NO.
0868 2E10366F NEXT:	LXI H,MUXCH	;CONTINUE
086C C7	MOV A,M	;RESTORE CH. NO.
086D 2E10366E	LXI H,RAW+1	;POINT TO LSBYTE STORE
0871 460008	CALL SHOLD	;GET DATA
0874 465401	CALL BINFP	;CONVERT TO F.P.
0877 461B08	CALL RVI	;CHANGE TO VOLTS
087A 2E103670	LXI H,RESLT	
087E 460F07	CALL OUU	;BCD←F.P.
0881 46C001	CALL DISPL	;DISPLAY
0884 49	IN 4	;SCAN ITT FOR INT
0885 1A	RAR	;SET CARRY FLAG
0886 606808	JC NEXT	;IF NO INT, GET
		;MORE DATA FROM
		;SAME CHANNEL
		;ELSE PROMPT
0889 467100	CALL CRLF	
088C 444708	JMP READ	
0000	END	


```

;
; DATA ACQUISITION ROUTINES
; THESE ROUTINES ARE USED TO UPDATE NUMERICAL
; LABELS AND TO PROVIDE EDITING CAPABILITY
; FOR ANNOTATING ANY GIVEN RUN.
; IN ADDITION, THE "WAIT" ROUTINES
; PROVIDE FOR VARIABLE TIME DELAYS BETWEEN
; GROUPS OF SAMPLED DATA POINTS
;
;
0000          ORG 08A0H
;
; EQUATES NOT ANNOTATED CAN BE
; FOUND IN PREVIOUS SECTIONS
;
000A          LF          EQU 0AH          ;LINE FEED
000D          SCHAR      EQU 0DH          ;STOP CHAR
1F00          BHEAD      EQU 1F00H        ;BUFF FOR "FILE"
0097          CNTRL      EQU 0097H        ;SYSTEM MONITOR
0065          DELAY      EQU 0065H        ;KILL TIME LOOP
007C          CO         EQU 007CH        ;CONSOLE OUT
00A1          RECOG      EQU 00A1H        ;COMMAND RECOGNITION
00FC          GETD       EQU 00FCH        ;INTO ANY BUFFER
0071          CRLF       EQU 0071H
00E8          LIST      EQU 00E8H
00F8          GET        EQU 00F8H
013A          STRIP      EQU 013AH
1040          DOPND      EQU 1040H
1070          RESLT      EQU 1070H
10A0          STACK      EQU 10A0H
00A5          NEWNO      EQU 0A5H          ;LSB OF COORD NO.
;
; MESSAGES
;
2603          LERR       EQU 2603H
267E          LWAIT      EQU 267EH
2629          LERR2      EQU 2629H
2793          LRUN       EQU 2793H
279C          LCOM       EQU 279CH
;
; 'COORD' UPDATES THE COORDINATION
; NUMBER OF A GIVEN RUN.
;
08A0 2E1036A5 COORD:    LXI H,STACK+5    ;LOAD COORDINATION
; NUMBER INTO
; A,B,C,D
08A4 C7          MOV A,M
08A5 31          DCR L
08A6 D7          MOV C,M
08A7 31          DCR L
08A8 DF          MOV D,M
08A9 0401        ADI 1                    ;INCREMENT AND
; DECIMAL ADJUST
08AB 3C3A        CPI 3AH                  ;>= ASCII 10 ?

```



```

08AD 40B408      JNC ADJ1      ;JUMP IF TRUE
08B0 C8          MOV B,A      ;ELSE RESTORE
08B1 44CD08      JMP DONE1    ;EXIT
08B4 0E30      ADJ1: MVI B,'0' ;RESET UNITS DIGIT
08B6 C2          MOV A,C      ;CHECK 10'S DIGIT
08B7 0401      ADI 1
08B9 3C3A      CPI 3AH
08BB 40C208     JNC ADJ2
08BE D0          MOV C,A
08BF 44CD08     JMP DONE1
08C2 1630      ADJ2: MVI C,'0' ;RESET 10'S DIGIT
08C4 C3          MOV A,D      ;CHECK 100'S DIGIT
08C5 0401      ADI 1
08C7 3C3A      CPI 3AH
08C9 40EB08     JNC ADJ3
08CC D8          MOV D,A
08CD 36A5      DONE1: MVI L,NEWNO ;STORE NEW NUMBER
08CF F9          MOV M,B
08D0 31          DCR L
08D1 FA          MOV M,C
08D2 31          DCR L
08D3 FB          MOV M,D
08D4 CF          MOV B,M      ;OUTPUT NEW NUMBER
08D5 467C00     CALL CO
08D8 30          INR L
08D9 CF          MOV B,M
08DA 467C00     CALL CO
08DD 30          INR L
08DE CF          MOV B,M
08DF 467C00     CALL CO
08E2 0E20      MVI B,' '      ;OUTPUT 2 SPACES
08E4 467C00     CALL CO
08E7 467C00     CALL CO
08EA 07          RET          ;BACK TO CALLER
08EB 1E30      ADJ3: MVI D,'0' ;OVERFLOW
08ED 44CD08     JMP DONE1

```

```

;
; "RUNNO" PRINTS OUT 'RUN NO. '
; IT IS ENTERED WITH 'CONTROL R', AND
; ENABLES THE USER TO INSERT DESIRED
; RUN NUMBER INFO.
;

```

```

08F0 2E273693 RUNNO: LXI H,LRUN ;'RUN NO. '
08F4 46E800     CALL LIST
08F7 2E113600   LXI H,1100H    ;BLANK PAGE
08FB 46FC00     CALL GETD
08FE 449700     JMP CNTRL

```

```

;
; "CMNT" IS USED TO FLAG AND ENTER
; A ONE LINE COMMENT.
;

```

```

0901 2E27369C CMNT: LXI H,LCOM ;'***** '
0905 46E800     CALL LIST
0908 2E113600   LXI H,1100H    ;BLANK PAGE

```



```

090C 46FC00          CALL GETD          ;INPUT COMMENT
090F 449700          JMP CNTRL          ;WHEN DONE, JUMP
;
; "EDIT" FORMATS THE "FILE" INFORMATION FOR
; LATER PRINT OUT. USES LF AS THE LAST
; ENTRY TO TERMINATE THE RECORD.
; "CONTROL F" IS USED TO EXIT THE ROUTINE ONLY
; AFTER EDITING AN EXISTING FILE. "CONTROL Z"
; IS USED TO STEP FORWARD THROUGH AN EXISTING
; RECORD IN ORDER TO SUBSTITUTE CHARACTERS.
; "RUBOUT" IS USED TO STEP BACKWARD THROUGH AN
; EXISTING RECORD IN ORDER TO SUBSTITUTE
; CHARACTERS ("RUBOUT" ALWAYS PRECEEDS THE
; NEW CHARACTER STRING).
;
0912 2E1F3601 EDIT:   LXI H,BHEAD+1      ;TOP OF BUFFER
0916 46FC00      ELOOP:  CALL GETD
0919 467100          CALL CRLF
091C 31          DCR L          ;FETCH LAST ENTRY
091D C7          MOV A,M
091E 3C0A          CPI LF        ;IF LF, THEN DONE
0920 689700          JZ CNTRL
0923 30          INR L          ;ELSE CONTINUE ENTRIES
0924 30          INR L
0925 441609          JMP ELOOP
;
; 'HDR' PRINTS OUT THE HEADER WHICH WAS
; ENTERED BY THE ABOVE ROUTINE.
; IT IS ALSO USED TO OUTPUT MULTI-LINE
; RECORDS WHICH END WITH A SEPARATE LF CR
; SEQUENCE. CONTAINS AN OVERRUN PROTECTION
; TO PREVENT AN INFINITE OUTPUT LOOP
; IN THE EVENT THAT THE FIRST CALL TO "EDIT"
; WAS ENDED WITH "CONTROL F" RATHER THEN LF.
; COMMAND WORD FOR ENTRY = "FILE"
;
0928 467100 HDR:      CALL CRLF
092B 467100          CALL CRLF
092E 2E1F3601      LXI H,BHEAD+1
0932 C7      HLOOP:  MOV A,M
0933 3C0D          CPI SCHAR      ;CHECK FOR EOL
0935 684B09          JZ NEXT
0938 3C0A          CPI LF        ;CHECK FOR EOR
093A 685109          JZ DONE2
093D C8          MOV B,A          ;PRINT CHARACTER
093E 467C00          CALL CO
0941 30      HLI:    INR L          ;GET ANOTHER
0942 C6          MOV A,L          ;CHECK FOR OVERRUN
0943 3C00          CPI 0
0945 685509          JZ ERR2
0948 443209          JMP HLOOP
094B 467100 NEXT:    CALL CRLF      ;EOL
094E 444109          JMP HLI
0951 467100 DONE2:   CALL CRLF

```



```

0954 07          RET
;
0955 2E263629 ERR2: LXI H,LERR2      ;ERROR MSG OUT
0959 46E800      CALL LIST
095C 07          RET
;
; "FILE" IS USED AS THE ENTRY POINT FOR THE
; OUTPUT OF THE MULTI-LINE RECORD ENTERED
; WITH "EDIT"."HLOOP" IS THE ENTRY POINT
; FOR MULTI-LINE RECORDS POINTED TO
; WITH HL. ALL SUCH RECORDS MUST END WITH
; A LF CR SEQUENCE.
; IN ADDITION, ALL SUCH RECORDS MUST NOT
; CROSS PAGE BOUNDARIES.
;
095D 462809 FILE:  CALL HDR
0960 449700      JMP CNTRL
;
; "WAIT" IS USED TO STORE A DELAY PARAMETER
; WHICH IS USED BY "SCAN" IN ORDER TO
; PROVIDE A DELAY BETWEEN DATA POINTS.
;
0963 2E26367E WAIT: LXI H,LWAIT
0967 463209      CALL HLOOP          ;PROMPT
096A 2E1036B0    LXI H,STACK+16      ;RESET WAIT FLAG
;TO TURN OFF
;DEFAULT OPTION
096E 3E00        MVI M,0
0970 44A100      JMP RECOG          ;GET WAIT FACTOR
;FROM OPERATOR
0973 2E1036AE MS25: LXI H,STACK+14   ;STORE 25MS DELAY
0977 3E53        MVI M,83           ;FINE STORAGE
0979 31          DCR L
097A 3E02        MVI M,2            ;COARSE DELAY
097C 449700      JMP CNTRL
097F 2E1036AE MS15: LXI H,STACK+14   ;STORE 15MS DELAY
0983 3E62        MVI M,98
0985 31          EXIT: DCR L
0986 3E01        MVI M,1
0988 449700      JMP CNTRL
098B 2E1036AE MS3:  LXI H,STACK+14   ;STORE 3MS DELAY
098F 3E17        MVI M,23
0991 448509      JMP EXIT
;
; "VWAIT" VARIABLE WAIT SUBROUTINE
; CALLED BY THE SCAN ROUTINE TO PROVIDE
; PROVIDE A DELAY BETWEEN DATA POINTS.
;
0994 2E1036AD VWAIT: LXI H,STACK+13  ;COARSE DELAY
0998 E7          MOV E,M            ;COUNTER
0999 30          INR L              ;FINE DELAY
099A DF          VLOOP: MOV D,M      ;FINE DELAY COUNTER
099B 466700      CALL DELAY+2
099E 21          DCR E

```


099F 489A09
09A2 07

JNZ VLOOP
RET

;
; THESE ROUTINES ARE USED TO IMPROVE
; OUTPUT READABILITY BY ROUNDING THE
; RESULT BUFFER TO 4 SIG DIGITS.
; "NOEX4" ASSUMES DATA NO LARGER THAN
; + OR - 9999, AND IS USED MAINLY
; FOR VOLTAGE OUTPUT. EITHER "YESEX"
; OR "NOEX4" MUST BE CALLED AFTER "ROUND".
;
;
;
; 'ROUND' IS USED TO OUTPUT 4 SIGNIFICANT
; DIGITS FROM THE DISPLAY REGISTER.
; A,B,E,H,L DESTROYED, NO INPUT RESTRICTIONS.
; MATH IS IN ASCII
;
;
;

09A3 2602	ROUND:	MVI E,2	;ENTRY COUNTER
09A5 2E1036AF		LXI H,STACK+15	;RESET OVERFLOW BIT
09A9 3E00		MVI M,0	
09AB 2E103679		LXI H,RESLT+9	
09AF 31	CONT1:	DCR L	;POINT TO LSD
09B0 C7		MOV A,M	;GET IT
09B1 3C2E		CPI '.'	;IF DP, JUMP
09B3 68BF09		JZ CONT2	
09B6 3E0D		MVI M,SCHAR	;ELSE INSERT CR
09B8 21		DCR E	;NEXT
09B9 48AF09		JNZ CONT1	;IF E=0, DONE
09BC 44C609		JMP SIG	;COMPUTE DIGITS
09BF 31	CONT2:	DCR L	
09C0 3E30		MVI M,30H	;INSERT ZERO
09C2 21		DCR E	;NEXT
09C3 48BF09		JNZ CONT2	;IF E=0, DONE
09C6 31	SIG:	DCR L	;POINT AT DIGIT
			; TO BE OPERATED ON
09C7 C7		MOV A,M	;GET TRIAL DIGIT
09C8 3C2E		CPI '.'	;IF DP GET NEXT
09CA 48D909		JNZ CONT3	;ELSE CONTINUE
09CD 31		DCR L	
09CE C7		MOV A,M	
09CF 3E30		MVI M,30H	;INSERT 0
09D1 3C35		CPI 35H	
09D3 600A0A		JC EXIT5	
09D6 44E009		JMP CONT5	
09D9 3C35	CONT3:	CPI 35H	;IF < 5 DO NOT ; ROUND
09DB 60070A		JC EXIT1	
09DE 3E0D		MVI M,SCHAR	;ELSE INSERT CR
09E0 2603	CONT5:	MVI E,3	;DIGIT COUNTER
09E2 31	CONT4:	DCR L	;POINT NEXT
09E3 C7		MOV A,M	;GET NEXT
09E4 3C2E		CPI '.'	;IF DP GET NEXT
09E6 68E209		JZ CONT4	


```

09E9 0401          ADI 1          ;ELSE INCR DIGIT
09EB 3C3A          CPI 3AH        ;IF < 10 DONE
09ED 60090A        JC EXIT2
09F0 3E30          MVI M,30H      ;ELSE RIPPLE CARRY
09F2 21            DCR E          ;NEXT DIGIT
09F3 48E209        JNZ CONT4

;
09F6 31            ;LAST: DCR L          ;GET LAST DIGIT
09F7 C7            MOV A,M
09F8 3C2E          CPI '.'        ;IF DP GET NEXT
09FA 68F609        JZ LAST
09FD 0401          ADI 1          ;INCR DIGIT
09FF 3C3A          CPI 3AH        ;IF OVERFLOW JUMP
0A01 68130A        JZ EXIT3
0A04 44090A        JMP EXIT2      ;ELSE PRINT

;
0A07 060D          EXIT1: MVI A,SCHAR ;NORMAL EXIT
0A09 F8            EXIT2: MOV M,A
0A0A 2E103670      EXIT5: LXI H,RESLT ;SIGN OUT
0A0E CF            MOV B,M
0A0F 467C00        CALL CO
0A12 07            RET
0A13 3E30          EXIT3: MVI M,30H ;INSERT 0
0A15 2E103670      LXI H,RESLT      ;DISPLAY BUFFER
0A19 CF            MOV B,M          ;SIGN OUT
0A1A 467C00        CALL CO
0A1D 0E31          MVI B,'1'        ;OVERFLOW DIGIT
0A1F 467C00        CALL CO
0A22 2E1036AF      LXI H,STACK+15 ;SET OVERFLOW FLAG
0A26 3E01          MVI M,1
0A28 07            RET

;
; "NOEX4" IS USED TO CHANGE FROM EXPONENTIAL
; FORMAT TO DECIMAL FORMAT FOR NUMBERS
; < .1 . MUST NOT BE USED FOR RESULTS
; >+ OR - 9999. AS THE ROUTINE ASSUMES ONLY
; SMALL NUMBERS ARE IN "E" FORMAT.
; USED TO IMPROVE THE READABILITY OF
; VOLTAGE OUTPUT.
; SIGN IS ASSUMED ALREADY OUT.
;
0A29 2E1036AF      NOEX4: LXI H,STACK+15 ;CHECK FOR OVERFLOW
0A2D C7            MOV A,M
0A2E 3C01          CPI 1
0A30 6A7E0A        CZ EXIT6        ;OUTPUT CARRY
0A33 2E103679      LXI H,RESLT+9    ;CHECK FOR E FORMAT
0A37 C7            MOV A,M
0A38 3C45          CPI 'E'
0A3A 48850A        JNZ EXIT7        ;IF NO, NORMAL EXIT
0A3D 2E10367C      LXI H,RESLT+12   ;GET # DECIMAL PLACES
0A41 C7            MOV A,M
0A42 2E1036AF      LXI H,STACK+15 ;SCRATCH
0A46 1431          SUI '1'          ;# LEADING 0'S
0A48 F8            MOV M,A          ;SAVE

```



```

0A49 E0          MOV E,A          ;COUNTER
0A4A 3C04        CPI 4
0A4C 406FOA      JNC ZERO         ;IF >3 0'S, NUMBER=0
0A4F 466FOA      CALL ZERO        ;OUTPUT LEADING 0'S
0A52 2E1036AF    LXI H,STACK+15
0A56 CF          MOV B,M          ;RESTORE
0A57 0604        MVI A,4          ;# SIG DIGITS
0A59 91          SUB B            ;DIGITS REMAINING
0A5A E0          MOV E,A          ;COUNTER
0A5B 2E103671    DGOUT: LXI H,RESLT+1 ;SKIP SIGN
0A5F CF          DLOOP: MOV B,M
0A60 467C00      CALL CO          ;DIGIT OUT
0A63 30          SKIPD: INR L
0A64 C7          MOV A,M
0A65 3C2E        CPI '.'         ;SKIP DP
0A67 68630A      JZ SKIPD
0A6A 21          DCR E
0A6B 485FOA      JNZ DLOOP
0A6E 07          RET
0A6F 0E2E        ZERO: MVI B,'.' ;LEADING 0'S OUT
0A71 467C00      CALL CO
0A74 0E30        MVI B,'0'
0A76 467C00      ZLOOP: CALL CO
0A79 21          DCR E
0A7A 48760A      JNZ ZLOOP
0A7D 07          RET
0A7E 2E103675    EXIT6: LXI H,RESLT+5 ;TRUNCATE LS 0
0A82 3E0D        MVI M,SCHAR
0A84 07          RET
0A85 2E103671    EXIT7: LXI H,RESLT+1 ;NORMAL EXIT
0A89 44E800      JMP LIST        ;RET THROUGH "LIST"

;
; "YESEX" IS USED TO RETAIN "E" FORMAT IN
; ORDER TO DISPLAY VERY LARGE OR VERY SMALL
; RESULTS. SIGN ASSUMED OUT.
;
0A8C 2E1036AF    YESEX: LXI H,STACK+15 ;CHECK FOR CARRY
0A90 C7          MOV A,M
0A91 3C01        CPI 1
0A93 6A7E0A      CZ EXIT6
0A96 2E103671    LXI H,RESLT+1    ;OUTPUT MANTISSA
0A9A 46E800      CALL LIST
0A9D 2E103679    LXI H,RESLT+9    ;OUTPUT EXP
0AA1 44E800      JMP LIST
0000            END

```



```

;
;
; SCAN ROUTINES
; PROVIDES THE LOGIC NESSARY TO TAKE
; 128 SETS OF DATA POINTS FOR UP EIGHT
; CHANNELS OF DATA (IN ANY ORDER) WITH USER
; DEFINED TIME DELAY. THE RESULT IS CONVERTED
; TO UNITS DEFINED BY THE USER.
;
; EQUATES NOT ANNOTATED CAN BE FOUND
; IN PREVIOUS SECTIONS.
;
1050      FOPND      EQU 1050H      ;FLOATING POINT
;OPERAND BUFFER
10A0      PAGE      EQU 10A0H      ;HIGH ADD FOR RAW
;DATA STORAGE
10C0      SCANB     EQU 10C0H      ;CHANNEL SEQUENCE BUFF
00C0      SCB       EQU 0C0H      ;START OF SCAN BUFF
10A0      STACK     EQU PAGE      ;START OF VARIABLE
;SCRATCH PAD
10A1      LINE      EQU PAGE+1     ;LOW ADD FOR RAW
;DATA STORAGE
10A2      CHNPT     EQU LINE+1     ;POINTS TO A LCN IN
;THE SCAN STORAGE BUFF
0080      CFB       EQU 080H      ;START OF CF BUFFER
0800      SHOLD     EQU 0800H      ;SAMPLE/HOLD/CONVERT
;COMMANDS FOR A/D
0994      VWAIT     EQU 0994H      ;VARIABLE TIME DELAY
08A0      COORD     EQU 08A0H      ;UPDATE COORDINATION #
09A3      ROUND     EQU 09A3H      ;ROUND OUTPUT BUFFER
;TO 4 SIG DIGITS
0A29      NOEX4     EQU 0A29H      ;CONVERT SMALL NOS.
;FROM "E" FORMAT
;TO "F" FORMAT
0A8C      YESEX     EQU 0A8CH      ;RETAIN "E" FORMAT
;WITH 4 SIG DIGITS
;FOR NUMBERS LT .1
;OR GT 9999999.
0145      DISPY     EQU 0145H      ;ASCII←BCD
0045      CI        EQU 0045H      ;CONSOLE INPUT
081B      RVI       EQU 081BH      ;RAW DATA TO VOLTS
;INTERPOLATION
; .0078125
0FE4      IS        EQU 0FE4H
00E8      LIST      EQU 00E8H
0071      CRLF      EQU 0071H
00F8      GET       EQU 00F8H
00FC      GETD      EQU 00FCH
1040      DOPND     EQU 1040H
1058      STORE     EQU 1058H
007C      CO        EQU 007CH
0097      CNTRL     EQU 0097H
0154      BINFP     EQU 0154H
036E      LOD       EQU 036EH
033E      STR       EQU 033EH
03D7      AD        EQU 03D7H

```



```

038C      MUL      EQU 038CH
1070      RESLT    EQU 1070H
070F      OUU      EQU 070FH
013A      STRIP    EQU 013AH
000D      SCHAR    EQU 0DH
;
0000      ;          ORG 0A00H
;
;  MESSAGES
;
26A7      LSCAN    EQU 26A7H
26C7      INFO     EQU 26C7H
2610      LERR1    EQU 2610H
26F3      C1       EQU 26F3H
26F7      C2       EQU 26F7H
26FF      C3       EQU 26FFH
2704      DWAIT    EQU 2704H
2730      EXP      EQU 2730H
;
;  'SCAN3' TAKES 128 SETS OF DATA
;  POINTS AT VARIABLE INTERVALS.
;
;  MACRO DEFINITIONS
;
; INRM      MACRO POINT,N          ; INCREMENT A MEMORY
;                                ; LOCATION N TIMES
;                                LXI H,POINT
;                                MOV A,M
;                                ADI N
;                                MOV M,A
;                                ENDM
;
;  COMMON SUBROUTINES
;
OAB0 2E1036A2 INDF:  LXI H,CHNPT          ; INDIRECT FETCH AND STORE
;                                ; IN 'A'. CHNPT CONTAINS
;                                ; LOW ADD. DATA ASSUMED
;                                ; ON SAME PAGE

OAB4 F7          MOV L,M
OAB5 C7          MOV A,M
OAB6 07          RET
OAB7 2E1036A0 INDP:  LXI H,PAGE          ; INDIRECT POINTER
;                                ; STORED IN FIRST 2
;                                ; STACK POSITS.
;                                ; SAVE

OABB DF          MOV D,M
OABC 30          INR L
OABD F7          MOV L,M          ; LOW POINT
OABE EB          MOV H,D          ; HIGH POINT
OABF 07          RET
OAC0 2E1036A0 SCAN2: LXI H,PAGE          ; INITIALIZE
OAC4 3E12          MVI M,12H          ; DATA INPUT BUFFER
OAC6 30          INR L
OAC7 3E00          MVI M,0          ; FIRST STORAGE LCN
OAC9 30          INR L

```


OACA 3ECO		MVI M,SCB	;START OF INFO BUFFER
OACC 07		RET	
	SKIP:	INRM CHNPT,1	;IGNORE DELIMITER
OACD 2E1036A2		LXI H,CHNPT	
OAD1 C7		MOV A,M	
OAD2 0401		ADI 00001H	
OAD4 F8		MOV M,A	
OAD5 46B00A		CALL INDF	;TEST NEXT CHAR
OAD8 3C08		CPI 8	
OADA 40CDOA		JNC SKIP	
OADD 07		RET	
OADE 2E1036A0	SCAN4:	LXI H,PAGE	;RE-INIT BETWEEN SCANS
OAE2 3E12		MVI M,12H	
OAE4 30		INR L	
OAE5 30		INR L	
OAE6 3ECO		MVI M,SCB	
OAE8 07		RET	
OAE9 46B70A	DATA:	CALL INDP	;POINT TO RAW STORAGE
OAEC 465401		CALL BINFP	;CONVERT TO F.P.
OAEF 2E103658		LXI H,STORE	;LOAD AND POINT
			; TO OPERAND
OAF3 466E03		CALL LOD	
OAF6 2E103650		LXI H,FOPND	
OAF8 07		RET	
	;		
	;		
	;		
OAFB 46B00A	SCAN3:	CALL INDF	;GET DESIRED CHANNEL
OAFE 3COD		CPI SCHAR	
OB00 68220B		JZ COUNT	;IF ALL CHANNELS SCANNED
			; SET UP NEXT STORAGE
OB03 3C08		CPI 8	;A>=8 ?
OB05 42CDOA		JNC SKIP	;IF TRUE, JUMP
OB08 46B70A		CALL INDP	
OB0B 30		INR L	
OB0C 460008		CALL SHOLD	;INPUT RAW DATA
		INRM PAGE,1	;NEXT CHANNEL
OB0F 2E1036A0		LXI H,PAGE	
OB13 C7		MOV A,M	
OB14 0401		ADI 00001H	
OB16 F8		MOV M,A	
		INRM CHNPT,1	;NEXT VECTOR POINTER
OB17 2E1036A2		LXI H,CHNPT	
OB1B C7		MOV A,M	
OB1C 0401		ADI 00001H	
OB1E F8		MOV M,A	
OB1F 44FBOA		JMP SCAN3	;GET NEXT DATA
	COUNT:	INRM LINE,2	;NEXT STORAGE
OB22 2E1036A1		LXI H,LINE	
OB26 C7		MOV A,M	
OB27 0402		ADI 00002H	
OB29 F8		MOV M,A	

OB2A 2B		RZ	;CHECK FOR END
OB2B 469409		CALL VWAIT	;KILL TIME
OB2E 46DE0A	RESET:	CALL SCAN4	;GET ANOTHER SET
OB31 44FBOA		JMP SCAN3	
	;		
	;		
	;		
	;		
	;	'SCAN5' TAKES SETS OF DATA FROM THE	
	;	CHANNEL ASSINGMENT DEFINED BY THE	
	;	'SET SCAN' ROUTINE.	
	;		
	;		
OB34 46D10B	SCAN5:	CALL COLMN	;PRINT COLUMN HEADINGS
OB37 467100		CALL CRLF	
OB3A 07		RET	;BACK TO CONTROLLER
OB3B 467100	RSCAN:	CALL CRLF	
OB3E 46A008		CALL COORD	;UPDATE COORDINATION
			;NUMBER
OB41 46C00A	CNTU7:	CALL SCAN2	;INIT FOR NEXT SCAN
			;ALSO ENTRY POINT FOR
			;SCANNING WITHOUT
			;COL HEADINGS
			;TAKE SET OF DATA
OB44 46FBOA		CALL SCAN3	
OB47 46C00A	DONE:	CALL SCAN2	
OB4A 46B00A	AVE:	CALL INDF	;GET CHANNEL
			; COMPUTE AVERAGE
OB4D 3C0D		CPI SCHAR	
OB4F 2B		RZ	;RETURN TO CALLER
OB50 3C08		CPI 8	
OB52 42CDOA		CNC SKIP	
OB55 2E1036A6		LXI H,STACK+6	;STORAGE FOR CONVERSION
			;FACTOR VECTOR.
OB59 D0		MOV C,A	;SAVE 'A'
OB5A B0		ORA A	;CLEAR CARRY
OB5B 12		RAL	;MPY BY 4
OB5C 12		RAL	
OB5D 0E80		MVI B,CFB	;START OF CONVERSION
			;FACTOR BUFFER
OB5F 81		ADD B	;COMPUTE VECTOR
OB60 F8		MOV M,A	;STORE VECTOR
OB61 C2		MOV A,C	;RESTORE 'A'
OB62 46E90A		CALL DATA	;CONVERT AND STORE
OB65 463E03		CALL STR	
	AVEL:	INRM LINE,2	;NEXT RAW DATA
OB68 2E1036A1		LXI H,LINE	
OB6C C7		MOV A,M	
OB6D 0402		ADI 00002H	
OB6F F8		MOV M,A	
OB70 68830B		JZ NEXTP	;IF DONE, OUT RESULTS
			;SETUP FOR NEXT SCAN
OB73 46E90A		CALL DATA	;CONVERT AND STORE
			;RAW DATA POINT
OB76 46D703		CALL AD	;ADD TO PREVIOUS

OB79 2E103650	LXI H,FOPND	;STORE PARTIAL SUM
OB7D 463E03	CALL STR	
OB80 44680B	JMP AVEL	
OB83 2E0F36E4 NEXTP:	LXI H,I5	;COMPUTE AVERAGE
		; AND CONVERT TO
		; VOLTAGE UNITS
		;A←.0078125
OB87 466E03	CALL LOD	
OB8A 2E103650	LXI H,FOPND	
OB8E 468C03	CALL MUL	;A←A*SUM
OB91 462208	CALL RVI+7	;A←VOLT(A)
OB94 2E1036A6	LXI H,STACK+6	;CONVERSION FACTOR
		;VECTOR
OB98 F7	MOV L,M	
OB99 468C03	CALL MUL	;CHANGE FROM VOLTS
		;TO USER DEFINED UNITS
OB9C 2E103670	LXI H,RESLT	
OBA0 460F07	CALL OUU	;CONVERT TO DECIMAL
OBA3 464501	CALL DISPY	;CONVERT TO ASCII
OBA6 46A309	CALL ROUND	;4 SIG DIGITS
OBA9 2E1036B1	LXI H,STACK+17	;FORMAT CHECK
OBAD C7	MOV A,M	
OBAE 3C59	CPI 'Y'	
OBBO 68250C	JZ EXPI	;IF TRUE,"E" FORMAT
OB3 46290A	CALL NOEX4	;ELSE "F" FORMAT
OB6 0E20 CNTU8:	MVI B,' '	;OUTPUT 2 SPACES
OB8 467C00	CALL CO	
OB8B 467C00	CALL CO	
	INRM PAGE,1	;P=P+1
OB8E 2E1036A0	LXI H,PAGE	
OBC2 C7	MOV A,M	
OBC3 0401	ADI 00001H	
OBC5 F8	MOV M,A	
	INRM CHNPT,1	;C=C+1
OBC6 2E1036A2	LXI H,CHNPT	
OBCA C7	MOV A,M	
OBCB 0401	ADI 00001H	
OBCD F8	MOV M,A	
OBCE 444A0B	JMP AVE	
OB81 2E1036A2 COLMN:	LXI H,CHNPT	;LOAD POINTER WITH
		;START OF SCAN BUFF
OB85 3EC0	MVI M,SCB	
OB87 2E1036B1	LXI H,STACK+17	
OB8B C7	MOV A,M	;CHECK FOR
		; "E" FORMAT
		;YES ? THEN CONTINUE
		;ELSE JUMP
		; ' # '
OB8C 3C59	CPI 'Y'	
OB8E 48F00B	JNZ CNTUD	
OB81 2E2636F3	LXI H,C1	
OB85 46E800	CALL LIST	
OB88 0E0D	MVI B,SCHAR	;CARRIAGE RETURN
OB8A 467C00	CALL CO	


```

OBED 44F70B          JMP CLOOP
OBFO 2E2636F3 CNTUD: LXI H,C1          ;' #'
OBF4 46E800          CALL LIST
OBF7 46B00A CLOOP:   CALL INDF          ;GET CHANNEL
OBFA 3C0D            CPI SCHAR
OBFC 2B              RZ                  ;RET WHEN DONE
OBFD 3C08            CPI 8              ;IGNORE DELIMITERS
OBFF 42CDOA          CNC SKIP
OC02 0430            ADI 30H            ;CONVERT TO ASCII
OC04 E0              MOV E,A            ;SAVE CH. NO.
OC05 2E1036B1        LXI H,STACK+17    ;CHECK FORMAT
OC09 C7              MOV A,M
OC0A 3C59            CPI 'Y'
OC0C 682B0C          JZ EXP2            ;IF TRUE, "E" FORMAT
                                           ;ADJUST HEADINGS
                                           ;' CH. '
OC0F 2E2636F7 CNTU9: LXI H,C2
OC13 46E800          CALL LIST
OC16 CC              MOV B,E            ;RECALL CH. NO.
OC17 467C00          CALL CO            ;OUTPUT
                                           ;C=C+1
OC1A 2E1036A2        LXI H,CHNPT
OC1E C7              MOV A,M
OC1F 0401            ADI 00001H
OC21 F8              MOV M,A

OC22 44F70B          JMP CLOOP
OC25 468C0A EXP1:    CALL YESEX          ;"E" FORMAT
OC28 44B60B          JMP CNTU8
OC2B 2E2636FF EXP2:  LXI H,C3            ;"E" FORMAT COL ADJ
OC2F 46E800          CALL LIST
OC32 440F0C          JMP CNTU9

;
; 'SSCAN' SET SCAN ENTRY POINT. PRINTS
; INSTRUCTIONS AND STORES THE NUMBER
; AND SEQUENCE OF CHANNELS TO BE SCANNED.
; IT ALSO SETS THE COORDINATION NUMBER
; TO ZERO.
OC35 2E1036A5 SSCAN: LXI H,STACK+5      ;RESET COORD #
OC39 3E30            MVI M,'0'
OC3B 31              DCR L
OC3C 3E30            MVI M,'0'
OC3E 31              DCR L
OC3F 3E30            MVI M,'0'
OC41 2E1036B0 PRM1:  LXI H,STACK+16     ;CHECK FOR WAIT FLAG
OC45 C7              MOV A,M
OC46 3C2A            CPI '*'
OC48 485E0C          JNZ CNTU5          ;JUMP IF NOT SET
OC4B 2E1036AD        LXI H,STACK+13     ;ELSE LOAD DEFAULT
                                           ;OF 15MS
OC4F 3E01            MVI M,1
OC51 30              INR L
OC52 3E62            MVI M,98
OC54 2E273604        LXI H,DWAIT       ;INFORM OPERATOR
OC58 46E800          CALL LIST

```



```

OC5B 467100          CALL CRLF
OC5E 2E273630 CNTU5: LXI H,EXP          ;ASK QUESTION
OC62 46E800          CALL LIST
OC65 2E1036B1        LXI H,STACK+17    ;"E" FORMAT FLAG STORE
OC69 464500          CALL CI           ;GET VALUE
OC6C 467C00          CALL CO           ;ECHO BACK
OC6F C1              MOV A,B           ;RESTORE A
OC70 3C4E            CPI 'N'
OC72 687A0C          JZ NOEXP          ;JUMP IF "N"
OC75 3E59            MVI M,'Y'        ;ELSE STORE "YES"
OC77 447C0C          JMP CNTU6
OC7A 3E4E            NOEXP: MVI M,'N'  ;ELSE STORE "NO"
OC7C 467100          CNTU6: CALL CRLF
OC7F 2E2636A7        LXI H,LSCAN      ;ASK QUESTION
OC83 46E800          CALL LIST
OC86 467100          CALL CRLF
OC89 2E1036C0        LXI H,SCANB      ;ENTER CHANNELS IN
                                ; DESIRED ORDER IN
                                ; THE SCAN BUFFER

OC8D 46FC00          CALL GETD
OC90 2E1036C0        LXI H,SCANB      ;CONVERT TO BCD
OC94 463A01          CALL STRIP
OC97 467100          CALL CRLF
OC9A 467100          CALL CRLF
OC9D 2E2636C7        LXI H,INFO      ;INSTRUCTIONS
OCA1 46E800          CALL LIST
OCA4 467100          CALL CRLF
OCA7 467100          CALL CRLF
OCAA 449700          JMP CNTRL        ;BACK TO MONITOR

;
; 'SCAN' EXECUTION POINT FOR MANUALLY SCANNING
; CHANNELS DEFINED ABOVE.
;
OCAD 2E1036C0 SCAN:  LXI H,SCANB      ;VALIDITY CHECK
OCB1 C7              MOV A,M
OCB2 3C2A            CPI '*'          ;BOOT DEFAULT
OCB4 68CA0C          JZ ERR1
OCB7 467100          CALL CRLF
OCBA 46340B          CALL SCAN5        ;START SCAN ROUTINE
OCBD 2E1036D0 LOOP:  LXI H,10DOH      ;WAIT FOR COMMAND
                                ;FROM OPERATOR

OCC1 46FC00          CALL GETD
OCC4 463B0B          CALL RSCAN        ;RESCAN FOR ANOTHER
                                ;SET OF DATA
OCC7 44BD0C          JMP LOOP          ;CONTINUE
OCCA 2E263610 ERR1:  LXI H,LERR1      ;MSG OUT
OCCE 46E800          CALL LIST
OCD1 449700          JMP CNTRL
0000                END

```



```

;
; EXTERNAL DEVICE DRIVER
; THIS SECTION CONTAINS THE LOGIC NECESSARY
; TO TURN ON TWO RELAYS ('UP' AND 'DOWN') IN
; ORDER TO CAUSE SOME PHYSICAL DEVICE TO
; MOVE TO A DESIRED LOCATION. SUBROUTINES
; LISTED HERE ARE ALSO USED BY THE SOFTWARE
; IN THE "RUN" SECTION IN ORDER TO
; PROVIDE AN AUTOMATIC CONTROL FUNCTION.
;
0000          ORG 0CE0H
; EQUATES NOT ANNOTATED CAN BE FOUND
; IN PREVIOUS SECTIONS.
;
10A0          STACK      EQU 10A0H
10A9          FCNT       EQU STACK+9          ;COUNTER IN NOISE
;FILTER ROUTINE
;OUTPUT PORT 1
0009          CMD        EQU 8+1             ;ACTIVATE "UP" RELAY
0030          CMDUP      EQU 30H             ;ACTIVATE "DOWN" RELAY
0050          CMDDN      EQU 50H
0010          OFF        EQU 10H             ;RELAYS OFF
0060          BUMP       EQU 60H             ;TRANSPORT DELAY
; (SEE TEXT)
106D          RAW        EQU 106DH           ;RAW DATA INPUT BUFR
0AE9          DATA      EQU 0AE9H          ; RAW DATA TO F.P.
;LOAD ACCUM AND POINT
;TO OPERAND
006A          HALF       EQU 006AH          ;4.5 MS DELAY
0831          VRI        EQU 0831H          ;VOLT UNITS TO
;BINARY A/D COUNT
081B          RVI        EQU 081BH          ;BINARY A/D COUNT TO
;VOLTAGE UNITS
1080          CFBUF      EQU 1080H          ;CONVERSION FACTORS.
0B41          CNTU7      EQU 0B41H          ;REMOTE ENTRY TO "SCAN"
;ROUTINES WITH COLUMN
;HEADINGS OFF
10C0          SCANB      EQU 10C0H          ;BUFFER CONTAINING
;CHANNELS TO BE SCANNED
;BIN←F.P.
0189          FPBIN      EQU 0189H
0800          SHOLD      EQU 0800H
000D          SCHAR      EQU 0DH
0065          DELAY      EQU 0065H
0071          CRLF       EQU 0071H
0097          CNTRL      EQU 0097H
00F8          GET        EQU 00F8H
013A          STRIP      EQU 013AH
0145          DISPY      EQU 0145H
00E8          LIST       EQU 00E8H
0154          BINFP      EQU 0154H
1040          DOPND      EQU 1040H
1050          FOPND      EQU 1050H
1058          STORE      EQU 1058H
033E          STR        EQU 033EH
036E          LOD        EQU 036EH

```



```

03D7      AD      EQU 03D7H
038C      MUL      EQU 038CH
03B4      DIV      EQU 03B4H
064B      INN      EQU 064BH
070F      OUU      EQU 070FH
0FE4      I5       EQU 0FE4H
;
;  MESSAGES
;
26FF      C3       EQU 26FFH
277F      LMOVE    EQU 277FH
;
;  COMMON SUBROUTINES
;
OCE0 C4    GT:      MOV A,E          ;RETURNS CARRY SET
;                                     ;IF BC>DE
OCE1 92     SUB C
OCE2 C3     MOV A,D
OCE3 99     SBB B
OCE4 07     RET
;
;
OCE5 46EBOC LT:      CALL SWAP      ;RETURNS CARRY SET
;                                     ;IF BC<DE
OCE8 46E00C CALL GT
;
;
OCEB C4     SWAP:    MOV A,E          ;DE←BC←DE
OCEC E2     MOV E,C
OCED D0     MOV C,A
OCEE C3     MOV A,D
OCEF D9     MOV D,B
OCFO C8     MOV B,A
OCF1 07     RET
;
;
OCF2 3601   AB:      MVI L,01        ;ABS(ACTUAL-DESIRED)
;                                     ;L=1 IF ACTUAL>
;                                     ;L=0 IF ACTUAL<
OCF4 46E00C CALL GT                ;IS DE>=BC ?
OCF7 40FEOC JNC YES                ;JUMP IF TRUE
OCFA 31     DCR L                    ;RESET FLAG
OCFB C2     MOV A,C
OCFC 94     SUB E
OCFD 07     RET
OCFE C4     YES:     MOV A,E
OCFF 92     SUB C
OD00 07     RET                ;ACTUAL>DESIRED
;
;
OD01 0610   DATA1:  MVI A,OFF        ;RELAYS OFF
OD03 2E10366E DATA2: LXI H,RAW+1    ;TAKE A SAMPLE FROM
;                                     ;CHANNEL 0. RELAY DIR
;                                     ;ASSUMED IN A

```



```

0D07 460008      CALL SHOLD
0DOA DF          MOV D,M          ;DE←SAMPLED DATA
0DOB 30          INR L
0DOC E7          MOV E,M
0DOD 31          DCR L          ;POINT TO SAMPLED DATA
0DOE 07          RET

;
; "BUMPM" IS USED TO PROVIDE AN EXTERNAL SIGNAL
; OF KNOWN TIME DURATION IN ORDER TO OBTAIN
; EXTERNAL DEVICE MOVEMENT (OPEN LOOP) OF A
; KNOWN AMOUNT. (SEE TEXT)
; INPUT: A=CHANNEL 0 PLUS RELAY DIRECTION
;        D=DESIRED DELAY PARAMETER
;
0DOF 53          BUMPM: OUT CMD          ;START RELAY
0DI0 466700      CALL DELAY+2          ;KILL TIME
0DI3 0610        MVI A,OFF          ;TURN RELAYS OFF
0DI5 53          OUT CMD
0DI6 07          RET
0DI7 1E60        BUMPU: MVI D,BUMP          ;MOVE UP A SHORT DIST
                                ;BUMP = DELAY

0DI9 0630        MVI A,CMDUP
0DIB 440F0D      JMP BUMPM
0DIE 1E60        BUMPD: MVI D,BUMP          ;MOVE DOWN A SHORT DIST
0D20 0650        MVI A,CMDDN
0D22 440F0D      JMP BUMPM

;
;
0D25 3C06        ADJU: CPI 6          ;IF LOCATION ERROR >5
                                ;COUNTS, MOVE UP
0D27 40980D      JNC UP
0D2A 3C03        CPI 3          ;IF LOCATION ERROR > 2
                                ;COUNTS, BUMP UP
0D2C 40170D      JNC BUMPU
0D2F 07          RET          ;CONVERGENCE EXIT

;
;
0D30 3C06        ADJD: CPI 6          ;ERROR ADJUSTMENT (AS
                                ;ABOVE) FOR THE DOWN
                                ;RELAY
0D32 40B90D      JNC DOWN
0D35 3C03        CPI 3
0D37 401E0D      JNC BUMPD
0D3A 07          RET          ;CONVERGENCE EXIT

;
;
0D3B 2E64        LONG: MVI H,100          ;1.0 SEC DELAY TO GIVE
                                ;TIME FOR RELAY AND
                                ;DRIVE MOTOR TO STOP
                                ;INNER LOOP COUNTER
0D3D 36D0        LOOPA: MVI L,ODOH
0D3F 31          LOOPB: DCR L
0D40 483F0D      JNZ LOOPB
0D43 29          DCR H
0D44 483D0D      JNZ LOOPA

```


0D47 07

RET

```

;
; "FLTR" IS USED TO FILTER OUT "GLITCHES" FROM
; THE A/D CONVERTER AND TO MINIMIZE THE EFFECT
; OF NOISE WHICH COULD MAKE THE
; EXTERNALLY CONTROLLED DEVICE STOP WITH AN
; ABSOLUTE ERROR (ACTUAL-DESIRED) GREATER THAN
; AN ACCEPTABLE AMOUNT.
;
0D48 2E1036A9 FLTR: LXI H,FCNT ;N=COUNT=127
0D4C 3E7F MVI M,127
0D4E 46010D CALL DATA1 ;STOP AND TAKE A SAMPLE
0D51 466A00 CALL HALF ;RELAY REACTION TIME
0D54 46EC0A CALL DATA+3 ;CONVERT/LOAD/POINT
0D57 463E03 CALL STR ;M←A(1)
0D5A 46010D LOOP: CALL DATA1 ;TAKE 127 MORE SAMPLES
;FORMING RUNNING SUM
0D5D 46EC0A CALL DATA+3
0D60 46D703 CALL AD ;A(N)←A(N)+M
0D63 2E103650 LXI H,FOPND
0D67 463E03 CALL STR ;M←A(N)
0D6A 2E1036A9 LXI H,FCNT
0D6E CF MOV B,M ;GET COUNTER
0D6F 09 DCR B ;N←N-1
0D70 F9 MOV M,B ;SAVE N
0D71 485A0D JNZ LOOP ;IF N>0, JUMP
0D74 2E103650 FAVE: LXI H,FOPND
0D78 466E03 CALL LOD ;A←SUM[A(N)]
0D7B 2E0F36E4 LXI H,I5
0D7F 468C03 CALL MUL ;A←A*.0078125
0D82 2E103650 LXI H,FOPND
0D86 463E03 CALL STR ;M←A
0D89 2E103650 LXI H,FOPND
0D8D 468901 CALL FPBIN ;BINARY←F.P.
0D90 2E1036A7 LXI H, STACK+7 ;FETCH DESIRED ANGLE
;BC←M
0D94 CF MOV B,M
0D95 30 INR L
0D96 D7 MOV C,M
0D97 07 RET
;
; "UP" AND "DOWN" ACTIVATE THEIR RESPECTIVE
; RELAYS IN ORDER TO DRIVE POSITION ERROR
; TO 'ZERO' (SEE TEXT)
;
0D98 0630 UP: MVI A,CMDUP ;A←UP COMMAND
0D9A 46030D CALL DATA2 ;TAKE SAMPLE
0D9D 46E00C CALL GT ;IF ACTUAL<DESIRED, UP
0DA0 60980D JC UP
0DA3 46480D CALL FLTR ;ELSE TURN OFF RELAY
;AND CHECK FOR NOISE
0DA6 46E00C CALL GT ;IF UNDERSHOOT, JUMP
0DA9 60980D JC UP
0DAC 463B0D CALL LONG ;WAIT FOR DRIVE MOTOR

```



```

ODAF 46F20C          CALL AB          ;TO STOP
                                ;COMPUTE ABSOLUTE VALUE
                                ;OF POSITION ERROR
ODB2 31              DCR L             ;TEST FLAG
ODB3 48250D          JNZ ADJU          ;UNDERSHOOT CORRECTION
ODB6 44300D          JMP ADJD          ;OVERSHOOT CORRECTION
                                ;EITHER ADJU OR ADJD
                                ;TESTS FOR CONVERGENCE
;
; THE ANNOTATION FOR THE "UP" ROUTINE APPLIES
; ALSO TO THE FOLLOWING ROUTINE.
;
ODB9 0650            DOWN: MVI A,CMDDN ;DOWN CONTROL
ODBB 46030D          CALL DATA2
ODBE 46E50C          CALL LT
ODC1 60B90D          JC DOWN
ODC4 46480D          CALL FLTR
ODC7 46E50C          CALL LT
ODCA 60B90D          JC DOWN
ODCD 463B0D          CALL LONG
ODD0 46F20C          CALL AB
ODD3 31              DCR L
ODD4 48250D          JNZ ADJU          ;OVERSHOOT CORRECTION
ODD7 44300D          JMP ADJD          ;UNDERSHOOT CORRECTION
;
; "MOVE" SENDS A MESSAGE TO THE OPERATOR
; AND READS IN THE DESIRED EXTERNAL
; DEVICE POSITION.
; INPUT: UNRESTRICTED
; REGISTERS: ALL
; OUTPUT: DESIRED POSITION IS IN DE
;          IN A/D BINARY UNITS
;
ODDA 2E27367F MOVE: LXI H,LMOVE      ;MESSAGE OUT
ODDE 46E800          CALL LIST
ODE1 467100          CALL CRLF
ODE4 46F800 MLOOP:  CALL GET          ;IN←DESIRED POSITION
                                ;IN USER UNITS
ODE7 2E103640        LXI H,DOPND
ODEB 463A01          CALL STRIP       ;BCD←ASCII
ODEE 2E103640        LXI H,DOPND
ODF2 464B06          CALL INN         ;F.P.←BCD
ODF5 2E103680        LXI H,CFBUF      ;CONVERSION FACTOR
ODF9 46B403          CALL DIV         ;VOLTS←USER UNITS
ODFC 463808          CALL VRI+7       ;ABSOLUTE←VOLTS
ODFF 2E103640        LXI H,DOPND
OE03 463E03          CALL STR         ;M←A
OE06 2E103640        LXI H,DOPND
OE0A 468901          CALL FPBIN       ;BINARY←F.P.
OE0D 07              RET              ;BACK TO CONTROLLER
;
; "CNTUA" AND "CNTUB" ARE A CONTINUATION
; OF THE ABOVE SUBROUTINE FOR MANUAL CONTROL
; OF THE EXTERNAL DEVICE.

```



```

;
OE0E 2E1036A7 CNTUA: LXI H,STACK+7 ;M←BINARY
OE12 FB MOV M,D
OE13 30 INR L
OE14 FC MOV M,E
OE15 46480D CALL FLTR ;TAKE A SAMPLE TO
; DETERMINE DRIVE
; DIRECTION.
; (UP OR DOWN)
; TURN ON "UP" RELAY
OE18 46E00C CALL GT
OE1B 603DOE JC MOVEU
OE1E 46E50C CALL LT ;TURN ON "DOWN" RELAY
; ELSE DO NOT MOVE
OE21 60430E JC MOVED
OE24 2E2636FF CNTUB: LXI H,C3 ;
OE28 46E800 CALL LIST
OE2B 2E1036C0 LXI H,SCANB ;LOAD CHANNEL 0 IN
; SCAN BUFFER
OE2F 3E00 MVI M,0
OE31 30 INR L
OE32 3E0D MVI M,SCHAR ;STOP AFTER 1 CHANNEL
; SCAN
OE34 46410B CALL CNTU7 ;128 POINT AVERAGE
; WITH PREVIOUSLY
; DEFINED DELAY AND
; FORMAT. THEN PRINT
; ACTUAL POSITION
OE37 467100 CALL CRLF
OE3A 444FOE JMP MANC1
;
; "MOVEU" AND "MOVED" ARE THE
; ENTRY POINTS TO THE "UP" AND "DOWN"
; CONTROL SUBROUTINES. (MANUAL OPS).
;
OE3D 46980D MOVEU: CALL UP
OE40 44240E JMP CNTUB
OE43 46B90D MOVED: CALL DOWN
OE46 44240E JMP CNTUB
;
; "MANC" IS THE ENTRY POINT FOR THE
; OPERATOR FOR MANUAL ACTUATION OF SOME
; MICROPROCESSOR CONTROLLED DEVICE.
;
OE49 46DA0D MANC: CALL MOVE
OE4C 440EOE JMP CNTUA
OE4F 46E40D MANC1: CALL MLOOP
OE52 440EOE JMP CNTUA
0000 END

```



```

; DIAGNOSTICS
; "DUMP" IS USED TO DISPLAY THE CONTENTS
; OF THE CONVERSION FACTOR BUFFER. "TEST"
; CHECKS ALL RAM BETWEEN 1000H AND 1FFFFH BY
; WRITING OUT A BYTE TO EACH LOCATION,
; READING IT BACK, AND COMPARING TO THE
; ORIGINAL VALUE. IF AN ERROR IS DETECTED,
; THE TTY BELL IS RUNG AND A MESSAGE IS
; PRINTED OUT ALONG WITH THE CONTENTS OF THE
; BAD MEMORY LOCATION AND IT'S ADDRESS.
;
0000          ORG 0E60H
; EQUATES NOT ANNOTATED CAN BE FOUND
; IN PREVIOUS SECTIONS.
;
0080          CFB      EQU 080H          ;LOW ADD OF CONVERSION
                                           ;FACTOR BUFFER
00A0          STK      EQU 0A0H          ;LOW ADDRESS OF STACK
007C          CO       EQU 007CH
10A0          STACK    EQU 10A0H
0071          CRLF     EQU 0071H
00E8          LIST     EQU 00E8H
0145          DISPY    EQU 0145H
0097          CNTRL    EQU 0097H
1070          RESLT    EQU 1070H
036E          LOD      EQU 036EH
070F          OUU      EQU 070FH
;
; MESSAGES
;
27A5          RAM      EQU 27A5H
;
0E60 2E1036A0 DUMP:    LXI H,STACK
0E64 3E80      MVI M,CFB          ;STARTING LOCATION
0E66 F7        DLOOP:  MOV L,M     ;GET VECTOR
0E67 466E03    CALL LOD          ;A←CONVERSION FACTOR
0E6A 2E103670  LXI H,RESLT
0E6E 460F07    CALL OUU          ;DUMP TO OUTPUT
                                           ;BUFFER
0E71 464501    CALL DISPY        ;ASCII←BCD
0E74 2E103670  LXI H,RESLT
0E78 46E800    CALL LIST        ;PRINTOUT INFO
0E7B 467100    CALL CRLF        ;NEW LINE
0E7E 2E1036A0  LXI H,STACK
0E82 C7        MOV A,M          ;FETCH VECTOR
0E83 0404      ADI 4            ;A←A+4
0E85 F8        MOV M,A          ;SAVE VECTOR
0E86 3CA0      CPI STK          ;CHECK FOR LAST
0E88 689700    JZ CNTRL         ;IF TRUE, DONE
0E8B 44660E    JMP DLOOP        ;ELSE GET NEXT
;
;
;

```



```

;
;
; "MTEST" IS USED TO CHECK EACH RAM LOCATION
; TO ENSURE IT IS ALL IN WORKING ORDER. IT
; ALTERNATELY WRITES ALL 0'S THEN ALL
; 1'S TO EACH CELL AND TESTS THAT THE VALUE
; READ BACK IS THE ONE IT SENT OUT.
OE8E 0600      MTEST: MVI A,0          ;FIRST TEST VALUE
OE90 2E103600  NEXT:  LXI H,1000H      ;RAM START LOCATION
OE94 C8        LOOP:  MOV B,A          ;SAVE A
OE95 F8        MOV M,A          ;WRITE TEST VALUE
OE96 C7        MOV A,M          ;READ TEST VALUE
OE97 B9        CMP B            ;IS IT THE SAME ?
OE98 48B60E    JNZ ERR3          ;IF NO JUMP
OE9B 30        INR L            ;POINT TO NEXT
OE9C 68A20E    JZ PC            ;CHECK PAGE CROSSING
OE9F 44940E    JMP LOOP          ;TRY ANOTHER
OEA2 28        PC:    INR H          ;NEXT PAGE
OEA3 C5        MOV A,H
OEA4 3C20      CPI 20H           ;LAST PAGE ?
OEA6 68AD0E    JZ NEW           ;IF YES, CHECK LAST
                                ;VALUE
OEA9 C1        MOV A,B          ;RESTORE
OEAA 44940E    JMP LOOP
OEAD C1        NEW:   MOV A,B          ;GET CURRENT TEST
                                ;VALUE
OEAE 3CFF      CPI OFFH         ;IS IT FFH
OEB0 2B        RZ               ;IF TRUE, DONE
OEB1 06FF      MVI A,OFFH       ;ELSE SET NEW VALUE
OEB3 44900E    JMP NEXT         ;RETEST RAM WITH
                                ;NEW VALUE
OEB6 46D10E    ERR3:  CALL HEXT          ;PRINT OUT BAD DATA
OEB9 0E2F      MVI B,'/'
OEBB 467C00    CALL CO
OEBE C5        MOV A,H
OEBF 46D10E    CALL HEXT          ;ADDRESS OUT
OEC2 C6        MOV A,L
OEC3 46D10E    CALL HEXT
OEC6 467100    CALL CRLF
OEC9 2E2736A5  LXI H,RAM          ;TELL OPERATOR
OECD 46E800    CALL LIST
OEDO 07        RET              ;DONE
;
; "HEXT" OUTPUTS HEX DATA IN ACCUM AS
; TWO ASCII DIGITS.
;
OED1 EO        HEXT:  MOV E,A          ;SAVE
OED2 1A        RAR              ;LO NIBBLE←HI NIBBLE
OED3 1A        RAR
OED4 1A        RAR
OED5 1A        RAR
OED6 46E40E    CALL HEX          ;OUTPUT ROUTINE
OED9 467C00    CALL CO
OEDC C4        MOV A,E          ;RESTORE
OEDD 46E40E    CALL HEX

```


0EE0 467C00		CALL CO	
0EE3 07		RET	
0EE4 240F	HEX:	ANI OFH	;MASK OFF HI NIBBLE
0EE6 3COA		CPI 10	;IS IT A NUMBER
0EE8 60ED0E		JC NUM	;IF TRUE, JUMP
0EEB 0407		ADI 7	;ELSE CONSTRUCT LETTER
0EED 0430	NUM:	ADI 30H	;ASCII BIAS
0EEF C8		MOV B,A	;OUTPUT REGISTER
0EF0 07		RET	
0000	END		


```

;
; THE AUTOMATIC CONTROL SECTION MAKES USE OF
; THE "MOVE" AND "SCAN" SECTIONS TO PROVIDE
; AUTOMATIC, INCREMENTAL STEPPING OF AN
; EXTERNAL DEVICE BETWEEN ARBITRARY LIMITS.
;
0000      ORG 2000H
; EQUATES NOT ANNOTATED CAN BE FOUND
; IN PREVIOUS SECTIONS
;
OCEB      SWAP      EQU OCEBH      ; DE←BC←DE
OCE0      GT        EQU OCE0H      ; DE-BC, RES NOT SAVED
OCE5      LT        EQU OCE5H      ; BC-DE, RES NOT SAVED
ODE4      MLOOP     EQU ODE4H      ; FETCH EXTERNAL
; POSIT, CONVERT, AND
; STORE IN DE
OD48      FLTR      EQU OD48H      ; GLITCH AND NOISE
; FILTER
OB3B      RSCAN     EQU OB3BH      ; RE-SCAN DESIRED
; CHANNELS AND PRINT
; RESULTS
OB34      SCAN5     EQU OB34H      ; PRINT OUT
; COLUMN HEADINGS
OCCA      ERR1      EQU OCCAH      ; TERMINAL ERROR
OD98      UP        EQU OD98H      ; TURN ON UP DRIVE
ODB9      DOWN     EQU ODB9H      ; TURN ON DOWN DRIVE
1060      N         EQU 1060H      ; ITERATION COUNTER
; FLOATING POINT
; STORAGE
1064      TEMP      EQU 1064H      ; TEMPORARY PRODUCT
; STORAGE
1068      FINC      EQU 1068H      ; F.P. REPRESENTATION
; OF INCREMENTAL DIST
; 1.0
; 819.15
OFEO      I6        EQU OFEOH
OFFO      I1        EQU OFFOH
000D      SCHAR     EQU 00DH
0071      CRLF      EQU 0071H
00E8      LIST      EQU 00E8H
0097      CNTRL     EQU 0097H
00F8      GET       EQU 00F8H
013A      STRIP     EQU 013AH
0154      BINFP     EQU 0154H
0189      FPBIN     EQU 0189H
1040      DOPND     EQU 1040H
1058      STORE     EQU 1058H
10A0      STACK     EQU 10A0H
10C0      SCANB     EQU 10C0H
1080      CFBUF     EQU 1080H
0080      CFB       EQU 0080H
033E      STR       EQU 033EH
036E      LOD       EQU 036EH
03D7      AD        EQU 03D7H
038C      MUL       EQU 038CH
03B4      DIV       EQU 03B4H

```



```

064B      INN      EQU 064BH
;
; MESSAGES
;
2672      LREAD    EQU 2672H
2746      START    EQU 2746H
2755      STOP     EQU 2755H
2764      INCRE    EQU 2764H
2772      LUNIT    EQU 2772H
;
; COMMON SUBROUTINES
;
; "LODXX" AND "STRXX" ARE USED FOR 2 WAY
; TRANSFER OF DATA BETWEEN CPU
; REGISTERS AND MEMORY.
;
2000 2E1036A7 STRD:   LXI H,STACK+7      ;CURRENT DESIRED
;POSITION STORAGE
2004 F9      MBC:    MOV M,B
2005 30      INR L
2006 FA      MOV M,C
2007 07      RET
2008 2E1036A7 LODD:   LXI H,STACK+7      ;BC←M
200C CF      BCM:    MOV B,M
200D 30      INR L
200E D7      MOV C,M
200F 07      RET
2010 2E1036B2 STRST:  LXI H,STACK+18     ;START POSITION
2014 440420   JMP MBC                      ;M←BC
2017 2E1036B2 LODST:  LXI H,STACK+18     ;BC←M
201B 440C20   JMP BCM
201E 2E1036B4 STRS:   LXI H,STACK+20     ;STOP POSITION
2022 FB      MDE:    MOV M,D
2023 30      INR L
2024 FC      MOV M,E
2025 07      RET
2026 2E1036B4 LODS:   LXI H,STACK+20     ;DE←M
202A DF      DEM:    MOV D,M
202B 30      INR L
202C E7      MOV E,M
202D 07      RET
202E 2E1036B6 STRI:   LXI H,STACK+22     ;INCREMENTAL POSITION
2032 442220   JMP MDE
2035 2E1036B6 LODI:   LXI H,STACK+22     ;DE←M
2039 442A20   JMP DEM
;
;
203C 2E103660 INCN:   LXI H,N            ;INCREMENT ITERATION
;COUNTER (N)
2040 466E03   CALL LOD                      ;A←N
2043 2E0F36E0   LXI H,I6
2047 46D703   CALL AD                      ;A=A+1
204A 2E103660   LXI H,N
204E 463E03   CALL STR                      ;N←A

```



```

2051 2E103668      LXI H,FINC      ;GET INCREMENT (I)
2055 468C03        CALL MUL        ;I←N*I
2058 2E103664      LXI H,TEMP      ;SAVE FACTOR
205C 463E03        CALL STR
205F 2E103664      LXI H,TEMP
2063 468901        CALL FPBIN      ;BINARY←F.P.
2066 462E20        CALL STRI       ;M←NEW INCREMENT
2069 463520  LOAD:  CALL LODI       ;LOAD START POSIT
                                           ;AND INCREMENT
206C 441720        JMP LODST
206F 460020  STOR:  CALL STRD       ;STORE NEXT POSIT
2072 442620        JMP LODS        ;LOAD STOP POSIT
;
;
; "INCP" AND "DECP" ARE USED TO INCREMENT/
; DECREMENT THE VALUE OF "DESIRED POSITION"
; BY "INCREMENT" AMOUNT.
; THE ROUTINE RETURNS WITH:
; BC←START POSIT+INCREMENT*N
; STACK+7←BC
; DE←STOP POSIT
;
2075 463C20  INCP:  CALL INCN      ;INPUT PARAMETERS
2078 C4      MOV A,E              ;ADD BC+DE AND STORE
                                           ;RESULT IN BC
2079 82      ADD C
207A D0      MOV C,A
207B C3      MOV A,D
207C 89      ADC B
207D C8      MOV B,A
207E 446F20  JMP STOR             ;EXIT THROUGH STORE
2081 463C20  DECP:  CALL INCN      ;INPUT PARAMETERS
2084 C2      MOV A,C              ;SUB DE-BC AND STORE
                                           ;RESULT IN BC
2085 94      SUB E
2086 D0      MOV C,A
2087 C1      MOV A,B
2088 9B      SBB D
2089 C8      MOV B,A
208A 446F20  JMP STOR             ;EXIT
;
;
208D 2E1036B8  SSUB: LXI H,STACK +24 ;SET SUBT FLAG
2091 3E01      MVI M,I
2093 441B21      JMP RUNL          ;BACK TO "RUN LOOP"
;
; "RUN" IS THE OPERATOR ENTRY POINT TO
; TO THE AUTOMATIC CONTROL ROUTINE. IT
; PROVIDES REPEATED SCANNING OF UP TO
; 8 CHANNELS AT SELECTED POSITIONS OF AN
; EXTERNAL DEVICE.
;
2096 2E1036C0  RUN:  LXI H,SCANB    ;VALIDITY CHECK
209A C7      MOV A,M

```


209B 3C2A	CPI '*'	;BOOT DEFAULT
209D 68CA0C	JZ ERR1	
20A0 2E273646	LXI H,START	;GET START POSITION
20A4 46E800	CALL LIST	
20A7 46E40D	CALL MLOOP	;CONVERT TO BIN
20AA 46EB0C	CALL SWAP	;BC←DE
20AD 460020	CALL STRD	;M←START
20B0 461020	CALL STRST	;M←START
20B3 467100	CALL CRLF	
20B6 2E273655	LXI H,STOP	;GET FINAL POSITION
20BA 46E800	CALL LIST	
20BD 46E40D	CALL MLOOP	;CONVERT TO BIN
20C0 461E20	CALL STRS	;M←STOP
20C3 467100	CALL CRLF	
20C6 2E273664	LXI H,INCRE	;GET INCREMENT
20CA 46E800	CALL LIST	
20CD 46F800	CALL GET	;INPUT←I
20D0 2E103640	LXI H,DOPND	
20D4 463A01	CALL STRIP	;BCD←ASCII
20D7 2E103640	LXI H,DOPND	
20DB 464B06	CALL INN	;F.P.←BCD
20DE 2E103680	LXI H,CFBUF	
20E2 46B403	CALL DIV	;I←VOLT(I)
20E5 2E0F36F0	LXI H,I1	
20E9 468C03	CALL MUL	;I←BIN(I)
20EC 2E103668	LXI H,FINC	
20F0 463E03	CALL STR	;M←I
20F3 2E103668	LXI H,FINC	
20F7 468901	CALL FPBIN	;DE←ABSOLUTE(M)
20FA 462E20	CALL STRI	;M←INCREMENT
20FD 2E103660	LXI H,N	;RESET COUNTER
2101 3E00	MVI M,0	
;		
2103 467100	CALL CRLF	
2106 46340B	CALL SCAN5	;COL HEADINGS
2109 460820	CALL LODD	;GET START AND STOP
		;POSIT TO DETERMINE
		;INCREMENT DIRECTION
210C 462620	CALL LODS	
210F 46E00C	CALL GT	;START>STOP ?
2112 608D20	JC SSUB	;IF YES, SET FLAG
2115 2E1036B8	LXI H,STACK+24	;ELSE RESET FLAG
2119 3E00	MVI M,0	
211B 46480D	RUNL: CALL FLTR	;TAKE POSIT READINGS
211E 46E00C	CALL GT	
2121 604C21	JC INCR	;IF DESIRED>ACTUAL,
		;MOVE UP
2124 46E50C	CALL LT	
2127 605221	JC DECR	;IF DESIRED<ACTUAL,
		;MOVE DOWN
212A 463B0B	CNTUC: CALL RSCAN	;ELSE TAKE A SET OF
		;CHANNEL READINGS
212D 2E1036B8	LXI H,STACK+24	;GET DIRECTION FLAG
2131 C7	MOV A,M	


```

2132 3C01          CPI 1
2134 684321        JZ DECR1          ;IF SET, DECREASE
                                   ;POSIT BY "I"
                                   ;ELSE INCREASE POSIT
2137 467520  INCR1: CALL INCP
213A 46E00C        CALL GT
213D 605821  TEST:  JC EXIT          ;IF STOP POSIT
                                   ;EXCEEDED, EXIT
                                   ;ELSE REPEAT
2140 441B21        JMP RUNL
2143 468120  DECR1: CALL DECP
2146 46E50C        CALL LT
2149 443D21        JMP TEST          ;CHECK FOR STOP
                                   ;POSIT EXCEEDED
                                   ;MOVE UP
214C 46980D  INCR:  CALL UP
214F 442A21        JMP CNTUC
2152 46B90D  DECR:  CALL DOWN        ;MOVE DOWN
2155 442A21        JMP CNTUC
2158 467100  EXIT:  CALL CRLF
215B 467100        CALL CRLF
215E 449700        JMP CNTRL
;
;
; "UNIT" IS USED TO INPUT CONVERSION FACTORS
; WHICH CHANGE THE INTERNAL UNITS (VOLTS)
; TO ANY UNIT DEFINED BY THE USER. ALL I/O
; OPERATION IS THEN IN TERMS OF THESE
; NEW UNITS UNTIL RESET.
;
2161 2E263672 UNIT: LXI H,LREAD      ;"CHANNEL = ?"
2165 46E800        CALL LIST
2168 46F800        CALL GET          ;INPUT CHANNEL
216B 2E103640      LXI H,DOPND
216F 463A01        CALL STRIP        ;BCD←ASCII
2172 2E103640      LXI H,DOPND
2176 C7            MOV A,M          ;GET CHANNEL
2177 B0            ORA A            ;CLEAR CARRY
2178 12            RAL              ;MPY BY 4
2179 12            RAL
217A 0480          ADI CFB          ;COMPUTE VECTOR
217C 2E1036A6      LXI H,STACK+6
2180 F8            MOV M,A          ;STORE IT
2181 467100        CALL CRLF
2184 2E273672      LXI H,LUNIT      ;"UNIT/VOLT =?"
2188 46E800        CALL LIST
218B 46F800        CALL GET          ;GET CONVERSION FACTOR
218E 2E103640      LXI H,DOPND
2192 463A01        CALL STRIP        ;BCD←ASCII
2195 2E103640      LXI H,DOPND
2199 464B06        CALL INN          ;F.P.←BCD
219C 2E1036A6      LXI H,STACK+6    ;GET VECTOR
21A0 F7            MOV L,M          ;POINT TO STORAGE
21A1 463E03        CALL STR          ;M←FACTOR
21A4 467100        CALL CRLF
21A7 446121        JMP UNIT          ;GET NEXT
0000              END

```



```

;
; ALL MESSAGES USED BY THE SYSTEM ARE
; CONTAINED IN THIS SECTION.
;
0000          ORG 2600H
;
000D          SCHAR EQU 0DH          ;STOP CHARACTER
000A          LF EQU 0AH          ;END OF RECORD
;
2600 3E200D    READY:  DB '> ',SCHAR
2603 204E4F54  LERR:   DB ' NOT DEFINED',SCHAR
2607 20444546
260B 494E4544
260F 0D
2610 30313A20  LERR1:  DB '01: CHANNELS '
2614 4348414E
2618 4E454C53
261C 20
261D 4E4F5420          DB 'NOT DEFINED',SCHAR
2621 44454649
2625 4E45440D
2629 30323A20  LERR2:  DB '02: INVALID '
262D 494E5641
2631 4C494420
2635 2246494C          DB '"FILE" '
2639 452220
263C 5445524D          DB 'TERMINATION',SCHAR
2640 494E4154
2644 494F4E0D
2648 2A2A2A20  LBOOT:  DB '*** RESET: ALL '
264C 52455345
2650 543A2041
2654 4C4C20
2657 4348414E          DB 'CHANNEL I/O IN '
265B 4E454C20
265F 492F4F20
2663 494E20
2666 22564F4C          DB '"VOLTS" ***',SCHAR
266A 54532220
266E 2A2A2A0D
2672 20434841  LREAD:  DB ' CHANNEL = ',SCHAR
2676 4E4E454C
267A 203D200D
267E 56414C49  LWAIT:  DB 'VALID FACTORS: ',SCHAR
2682 44204641
2686 43544F52
268A 533A200D
268E 41203D20          DB 'A = 3MS',SCHAR
2692 334D530D
2696 42203D31          DB 'B =15MS',SCHAR
269A 354D530D
269E 43203D32          DB 'C =25MS',LF,SCHAR
26A2 354D530A
26A6 0D

```



```

26A7 494E5055 LSCAN: DB 'INPUT CHANNELS'
26AB 54204348
26AF 414E4E45
26B3 4C53
26B5 20494E20 DB ' IN DESIRED '
26B9 44455349
26BD 52454420
26C1 4F524445 DB 'ORDER',SCHAR
26C5 520D
26C7 5748454E INFO: DB 'WHEN READY TO '
26CB 20524541
26CF 44592054
26D3 4F20
26D5 54414B45 DB 'TAKE DATA, '
26D9 20444154
26DD 412C20
26E0 54595045 DB 'TYPE SCAN '
26E4 20205343
26E8 414E20
26EB 4F522052 DB 'OR RUN ',SCHAR
26EF 554E200D
26F3 2023200D C1: DB ' # ',SCHAR
26F7 20202043 C2: DB ' CH. ',SCHAR
26FB 482E200D
26FF 20202020 C3: DB ' ',SCHAR
2703 0D
2704 44454C41 DWAIT: DB 'DELAY BETWEEN '
2708 59204245
270C 54574545
2710 4E20
2712 44415441 DB 'DATA POINTS = '
2716 20504F49
271A 4E545320
271E 3D20
2720 3135204D DB '15 MS (DEFAULT)',SCHAR
2724 53202844
2728 45464155
272C 4C54290D
2730 22452220 EXP: DB '"E" FORMAT'
2734 464F524D
2738 4154
273A 2859204F DB '(Y OR N) ? ',SCHAR
273E 52204E29
2742 203F200D
2746 53544152 START: DB 'START POSIT = ',SCHAR
274A 5420504F
274E 53495420
2752 3D200D
2755 53544F50 STOP: DB 'STOP POSIT = ',SCHAR
2759 20504F53
275D 49542020
2761 3D200D

```



```

2764 494E4352 INCRE: DB 'INCREMENT = ',SCHAR
2768 454D454E
276C 5420203D
2770 200D
2772 554E4954 LUNIT: DB 'UNIT/VOLT = ',SCHAR
2776 2F564F4C
277A 54203D20
277E 0D
277F 44455349 LMOVE: DB 'DESIRED .... '
2783 52454420
2787 2E2E2E2E
278B 20
278C 41435455 DB 'ACTUAL',SCHAR
2790 414C0D
2793 52554E20 LRUN: DB 'RUN NO. ',SCHAR
2797 4E4F2E20
279B 0D
279C 2A2A2A2A LCOM: DB '***** ',SCHAR
27A0 2A202020
27A4 0D
27A5 07444154 RAM: DB 07H,'DATA/'
27A9 412F
27AB 4C4F4341 DB 'LOCATION'
27AF 54494F4E
27B3 202E2E2E DB ' ..... BAD RAM'
27B7 2E2E2E20
27BB 42414420
27BF 52414D
27C2 070D DB 07H,SCHAR
0000 END

```



```

;
;
; JUMP TABLE
;
; THE RECOGNITION ROUTINE ("RECOG", 00A1H)
; COMPARES THE CHECK-SUM IT COMPUTES WITH
; EVERY THIRD ENTRY IN THIS TABLE. IF A
; MATCH IS FOUND, THE FOLLOWING TWO BYTES
; SHOW THE ENTRY POINT FOR THE DESIRED
; ROUTINE.
;
; 00H MARKS THE END OF THE TABLE.
;
0000          ORG 0F00H
;
; EQUATES
;
0847          READ      EQU 0847H          ;VOLTMETER FUNCTION
08F0          CNTLR     EQU 08F0H          ;"RUN NO. "
0901          CNTLC     EQU 0901H          ;"***** " COMMENT
0912          EDIT      EQU 0912H          ;TEXT INPUT
095D          FILE      EQU 095DH          ;WRITE TEXT
0963          WAIT      EQU 0963H          ;DELAY FACTOR
098B          A1        EQU 098BH          ;3 MS DELAY
097F          B1        EQU 097FH          ;15 MS DELAY
0973          C1        EQU 0973H          ;25 MS DELAY
0C35          SSCAN     EQU 0C35H          ;SET SCAN ROUTINE
0CAD          SCAN      EQU 0CADH          ;TAKE DATA
0E49          MOVE      EQU 0E49H          ;MANUAL CONTROL
0E60          DUMP      EQU 0E60H          ;CONVERSION FACTORS
0E8E          MTEST     EQU 0E8EH          ;RAM CHECK
2096          RUN       EQU 2096H          ;AUTOMATIC CONTROL
2161          UNIT      EQU 2161H          ;INPUT SCALE FACTORS
;
0F00 1C       J1:      DB 1CH
0F01 4708     DW READ
0F03 12       J2:      DB 12H
0F04 F008     DW CNTLR
0F06 03       J3:      DB 03H
0F07 0109     DW CNTLC
0F09 26       J4:      DB 26H
0FOA 1209     DW EDIT
0F0C 20       J5:      DB 20H
0F0D 5D09     DW FILE
0F0F 35       J6:      DB 35H
0F10 6309     DW WAIT
0F12 41       J7:      DB 41H
0F13 8B09     DW A1
0F15 42       J8:      DB 42H
0F16 7F09     DW B1
0F18 43       J9:      DB 43H
0F19 7309     DW C1
0F1B 31       J10:     DB 31H
0F1C 350C     DW SSCAN

```


OF1E 25	J11:	DB 25H
OF1F ADOC		DW SCAN
OF21 37	J12:	DB 37H
OF22 490E		DW MOVE
OF24 36	J13:	DB 36H
OF25 600E		DW DUMP
OF27 8D	J14:	DB 8DH
OF28 8E0E		DW MTEST
OF2A F5	J15:	DB 0F5H
OF2B 9620		DW RUN
OF2D 40	J16:	DB 40H
OF2E 6121		DW UNIT
OF30 00	STOP:	DB 00H


```

;
; CONSTANT STORAGE
;
; THE FOLLOING DATA ARE THE FLOATING
; POINT REPRESENTATION OF CONSTANTS
; USED THROUGHOUT THE PROGRAM
;

```

```

OF31                                ORG OFEOH
OFE0 81000000 I6:                   DB 81H,0,0,0      ;1.0
OFE4 7A000000 I5:                   DB 7AH,0,0,0      ;.0078125
;
OFE8                                ORG OFFOH
OFF0 8A4C      I1:                   DB 8AH,4CH
OFF2 C99A      DB 0C9H,9AH          ;819.15
OFF4 84200000 I2:                   DB 84H,20H,0,0    ;10.0
OFF8 8A4C      I3:                   DB 8AH,4CH
OFFA C99A      DB 0C9H,9AH          ;819.15
OFFC 8D7F      I4:                   DB 8DH,7FH
OFFE FC00      DB 0FCH,0            ;8191.15
0000                                END

```


VI. RECOMMENDATIONS

The ADL software was developed on an existing development system which used the following:

1. 110 baud teletype for program listing.
2. 110 baud paper tape punch for mass storage.
3. 1200 baud high speed paper tape reader.
4. 1200 baud CRT for program entry and editing.

While this system is a useful tool for writing and debugging small programs, it is not a viable system for large scale development. The percentages of time devoted to the creation of the ADL software package was 15% logic development, 5% manual entry, 15% debugging and 75% waiting for paper tape and teletype output. The last figure represents a significant and costly waste of manpower assets. The following system - while more expensive - could easily pay for itself in man-hour savings alone:

1. Floppy disk mass memory. this reduces an edit-assembly-reedit-reassembly cycle from up to eight hours (for the entire package) to less than five minutes (also for the entire package).
2. Line printer for producing source code and assembly listings.
3. Resident high level language such as BASIC or PL/M to enhance complex logic manipulations.

The Department of Aeronautics has recently acquired the

INTEL MDS 80 development system. This system contains the above components and is presently being used as a data acquisition system for an oscillating flow wind tunnel. In addition to data logging, this system can perform on-line fast fourier analysis of data taken in a highly turbulent and non-linear environment [2].

Microprocessor usage presents a unique problem; namely, better CPUs and more advanced peripherals appear on the market almost monthly. Therefore, a U-P oriented system rapidly becomes outdated. The software for the ADL was written using industry standard techniques. A change to the more advanced 8080 CPU can therefore be accomplished (with minor changes) by simply reassembling the program with an 8080 assembler. Such an update is recommended if the ADL is to be used to take higher frequency data.

APPENDIX A

GLOSSARY

1. A/D: analog to digital (adjective or noun)
2. assembly: A listing which contains both source code and machine code.
3. BAUD: A data transmission rate expressed in BITS per second.
4. BIT: BInary digiT. A single unit of information in a binary word.
5. buffer: A group of memory locations used to store specific data (input data, constants, output data, etc.).
6. buffering: A process by which electronic signals possessing different properties are made compatible.
7. byte: An eight-BIT word which is processed as a single quantity.
8. CPU: Central Processing Unit. The area of the microprocessor which computes and sequences all logic and arithmetic functions.
9. coordination number: A sequential, numerical label associated with a set of data points for a given run.
10. CRT: Cathod Ray Tube. Also used as the generic name for a television type display.
11. D/A: The inverse of the A/D process.

12. data logging: The acquisition and tabulation of data.
13. EPROM: erasable/programmable read only memory
14. driver: In a software context this term refers to a program used to control the actions of an external device.
15. external device: A physical device which is not an integral part of the microprocessor.
16. glitch: A missing BIT in a byte of data which can occur during data transmission or conversion.
17. H: A suffix which indicates a hexadecimal number (Appendix C).
18. I/O: input/output
19. K: A suffix which indicates a group of $1024 (2^{10})$ items as in '4K of memory' meaning 4096 memory locations.
20. machine code: The BIT patterns actually used by the U-P in order to carry out its assigned logic functions.
21. MUX: a multiplexing device
22. nibble: The upper or lower four BITS in one byte.
23. OS: Operating System. Another term for Software Package.
24. page: a 256 byte segment of memory
25. RAM: Random access memory. Volatile memory used for variable storage and data manipulation.
26. register: A storage location located in the CPU.
27. ROM: read only memory, non-volatile
28. software: The program which resides in the U-P's memory.

- 29. source code: The program written by the user.
- 30. U-P: microprocessor
- 31. 8008: An 8-BIT U-P device.
- 32. 8080: The next generation U-P from the 8008.

APPENDIX B

VENDOR DATA

The following specification sheets give the major properties of the hardware used in the ADL system. Also presented are the I/O pin assignments for the 805 processor as well as the pin-outs for the other connectors used throughout the system.

MPS 805 MICROPROCESSOR SYSTEM SPECIFICATIONS

Physical

Three 4.5" by 6.5" printed circuit cards

- One 8111 CPU card
- One 8114 Input card
- One 8115 Output card
- One 8116 ROM card
- One 8117 RAM card

Connector Requirement for each card

56 pin, 28 position dual row-out on 0.125" centers

CPU Card includes

- 8008 CPU
- Crystal clock
- Address latches, data buffers, and control decode circuits
- Power-on and external restart
- DMA buffers

ROM Card includes

- One 1702A PROM (256 bytes) and eight PROM sockets
- Socket for card expansion circuit (up to 8 cards)

RAM Card includes

- Eight 2102 RAM (1024 bytes) and thirty-two RAM sockets
- Socket for card expansion circuit (up to 4 cards)

Input Card includes

- 12 TTL input selector circuits addressable in groups of 8
- Socket for card expansion circuit (up to 2 cards)

Output Card includes

- 12 TTL output latch circuits addressable in groups of 8
- Socket for card expansion circuit (up to 6 cards)

Operational

CPU

- Executes all of the 8008 instructions
- 4 microsecond time state cycle using 8008 (MPS 1805).
- 2.8 microsecond time state cycle using 8008-1 (MPS 805-1).

Memory for data or program storage card expandable to any combination of ROM and RAM to 16384 words

- ROM, 2048 word capacity per card
- RAM, 4096 word capacity per card

Input and Output

- Input gates implement the INP instructions.
- Output latches implement the OUT instructions.

Interrupt or External Restart

- Single line, synchronized interrupt on CPU card can be optionally wired for multi-level interrupt or Power-on external restart.
- Multi-level Interrupt: Control lines available for external interrupt such as 8118 priority interrupt card.
- Power-on and external restart option: CPU starts at instruction location 0000 by wiring restart output from CPU card to Interrupt Request input

DMA (Direct Memory Access)

- Data, address, and control lines are 3-state disconnected by the CPU following a HLT instruction allowing DMA by peripherals. The CPU must be interrupted to continue following a HALT

Electrical Requirements

Refer to individual data sheets and schematics on the 8111, 8114, 8115, 8116, and 8117 for interface and wiring.

Power Requirements for the five card set fully loaded

- +VCC = $\pm 5\%$ @ 3.3 Amp maximum (35mA per ROM, 50mA per RAM)
- GND 0 volts
- VDD = -9 volts $\pm 5\%$ @ 900 mA maximum (35 mA per ROM)

Hardware

- Compatible with Series 8400 interface cards.
- Fits CR5, CR10 or CR19 card racks
- Use M273 power supply
- PROM's programmable on Series 81 programmers

Software

- MPS 800 hardware is fully compatible with any 8008 software assuming I/O and interrupt can be assigned compatibly. Teletype operating system and system monitor available. Assemblers, compilers and simulators available through computer time sharing services.




8 CHANNEL ANALOG MULTIPLEXER MODEL MM-8

FOR ANALOG TIME SHARING - \$69 each

FEATURES

- ☐ Small size 1" x 2" x 0.375"
- ☐ Low power consumption 300 milliwatts
- ☐ High transfer accuracy $\pm 0.01\%$
- ☐ Fast settling output 1 microsecond to $\pm 0.01\%$ of FS.
- ☐ Choice of input type Single ended or differential
- ☐ Completely self contained ... Includes 8 MOS-FET switches, drivers and decoding logic for channel selection

BLOCK DIAGRAM






SAMPLE AND HOLD

MODEL SHM-4

FOR SIMULTANEOUS SAMPLE AND HOLD APPLICATIONS

FEATURES

- ☐ Fast Acquisition Time $6 \mu\text{sec}$
- ☐ Low Droop $20 \mu\text{V/rnsec}$
- ☐ Adjustable Aperture Delay To zero between units
- ☐ Low Gain Error $\pm .005\%$
- ☐ High Input Impedance $100 \text{ M}\Omega$



DESCRIPTION

The SHM-4 is ideally suited to simultaneous sample and hold applications, where the gain and aperture delay between units must be matched, and where the output droop of the sampled signal is minimized for time shared A/D conversion.

A double inversion circuit in the SHM-4 places the FET sampling switch near ground, which means that all variations of hold step and of aperture delay with input voltage are eliminated.

A unique closed loop design gives high accuracy and allows the rate error¹ to be factory nulled. Rate error is the delay by which the output lags an input ramp and may be expressed in nsec or in mV/V/ μ sec. For conventional sample and hold applications rate error is not serious because it merely causes an advance in the effective time of hold and tends to cancel out part of the aperture delay. However, for simultaneous applications the aperture delay minus the rate error must be matched between units so that the effective time of hold is the same for all. The SHM-4 accomplishes this by nulling the rate error to less than 1 nanosecond and for critical applications, by providing an external 5 nanosecond adjustment of aperture delay. Also, the high accuracy and low droop of the SHM-4 make it useful in conventional sample and hold applications.

Careful attention to circuit detail in eliminating leakage currents has decreased the output droop to less than 20 microvolts per millisecond allowing several SHM-4 modules to be time shared between one A/D converter.

¹ Dynamic Accuracy of Sample and Hold Circuits, Datel Systems, Inc., Application Note V1-1.

Datel's Model MM-8 is a complete eight channel solid state analog multiplexer designed for applications which require fast output settling and high transfer accuracy.

The entire multiplexer is self contained in a plastic module measuring 0.8 cubic inches. It contains eight MOS-FET switches with associated driver circuits, each having a current limiter pull-up FET to provide minimum propagation delay, also included is all the necessary decoding logic to enable random channel addressing with a four bit parallel binary input. Two MM-8 multiplexers can be cascaded to provide up to sixteen channels under command from one 4-BIT address. The addressing logic inputs are compatible with DTL/TTL logic levels.

Full scale inputs can be either $\pm 5V$ or $\pm 10V$ with a transfer accuracy (input to output) of $\pm 0.01\%$, provided the output load is a minimum of 10 megohms. The high impedance amplifier provided with Datel's ADC-E, ADC-L and ADC-M series analog/digital converters and SHM Series sample/hold's are quite suitable for this application.

Output settling time for each channel is one microsecond to $\pm 0.01\%$ of full scale and each channel can sequentially switch at a 500 KHz rate. The output of the eight channels is divided into two parallel groups of four.


As stated before, MM-8 is complete and requires only +5VDC, +15VDC and -15VDC (-20VDC) for operation.

MM-8 modules are 2"L x 1"W x 0.375"H in size come fully encapsulated, and feature dual in line pinning (0.100" grid pin spacing)

HIGH RESOLUTION ANALOG-TO-DIGITAL CONVERTER

MODEL ADC-149

Datel Systems' products are manufactured to high standards of workmanship and are carefully tested to ensure reliable operation. Our delivered products have experienced exceptionally low failure rates. In the event that you experience a malfunction with the product, first carefully check the connections and calibration of the device against the enclosed data sheet. If the problem persists and appears to be an internal malfunction, call the nearest Datel Sales Office for instructions on how to return the unit. Returns must be authorized by the factory and must be shipped prepaid.



GENERAL DESCRIPTION

The ADC-149 is a 14 bit successive approximation type analog to digital converter for OEM use. It was specifically designed to give high resolution and accuracy at moderate cost for incorporation into precision instruments for process control systems and test and measurement systems.

The ADC-149 can resolve 1 part in 16,384 giving an operating dynamic range of 84.3dB. On the 10 volt full scale range it can detect an input change of less than 1 millivolt. Accuracy is adjustable to $\pm 0.005\%$ of full scale $\pm \frac{1}{2}$ LSB. The temperature coefficient is held to a low $\pm 15\text{ppm}/^\circ\text{C}$ over the 0° to 70°C operating temperature range.

This converter accepts either unipolar or bipolar input voltages of 0 to -10V , 0 to -20V , $\pm 5\text{V}$, or $\pm 10\text{V}$ full scale by external pin connection and performs a 14 bit conversion in $50\text{ }\mu\text{sec}$. Several output codes are available including straight binary for unipolar inputs and either offset binary or two's complement for bipolar inputs. Two's complement is obtained by using the $\overline{\text{MSB}}$ output pin. Reverse coding sense is used with the most negative analog input corresponding to full scale digital output. A serial data output is also provided and has a nonreturn-to-zero (NRZ) format. Logic outputs are DTL/TTL compatible and will drive 6 standard TTL loads.

ADL PIN CONNECTIONS

A/D Card Code...

22 Pin plug

Pin Ident.

No.

1 NC

2 NC

3 NC

4 NC

5 Ch. 0

6 Ch. 1

7 Ch. 2

8 Ch. 3

9 Ch. 4

10 Ch. 5

11 Ch. 6

12 Ch. 7

13 NC

14 Relay plug (spare)

15 Relay plug (Alpha Relay)

16 Relay plug (Alpha Relay)

17 Relay plug (Gnd.)


18 NC

19 +5 VDC

20 +15 VDC Pwr. Supply

21 Gnd. Buss line

22 -15 VDC



From P3 on Prolog Rack

Input (Command) 16 pin socket

Pin Ident.

No.

1 MUX Ch. 001

2 MUX Ch. 010

3 MUX Ch. 100

4 S/H Command

5 A/D Start

6 Alpha Relay (Incr.)

7 Alpha Relay (Decr.)

8 Relay Plug (spare)

9 to 16 Not used

Relay Plug

A to P14 Spare Relay

B P17 Gnd. (Logic)

C P15 alpha relay (incr.)

D P16 alpha relay (decr.)

E P21 Gnd. (Buss)

Output (Data) 16 pin socket

1 A/D Bit 14 (LSB)

2 " " 13

3 " " 12

4 " " 11

5 " " 10

6 " " 9

7 " " 8

8 " " 7

9 " " 6

10 " " 5

11 " " 4

12 " " 3

13 " " 2

14 " " 1 (MSB)

15 A/D E.O.C.

16 Spare

ADL PIN CONNECTIONS

PROLOG SYSTEM 44 Pin Output Plug (On Top of Card Rack)

CODE

Pin Ident.

No.

1	Out 1-8	to	P3-8	Relay Plug (spare)
2	" 1-7		P3-7	Alpha Relay (decr.)
3	" 1-6		P3-6	Alpha Relay (incr.)
4	" 1-5		P3-5	A/D Start
5	" 1-4		P3-4	S/H Command
6	" 1-3		P3-3	Analog MUX Ch. 100
7	" 1-2		P3-2	" MUX Ch. 010
8	" 1-1		P3-1	" MUX Ch. 001
9	NC			
10	Out 3-8		P4-15	DP (Dec. Pt., Lite Chip 03)
11	" 3-7		P4-14	DP (Lite Chip 02)
12	" 3-6		P4-13	DP (Lite Chip 01)
13	" 3-5		P4-12	DP (lite Chip 00)
14	" 3-4		P4-8	BCD Data 8 (to Lites)
15	" 3-3		P4-7	BCD Data 4
16	" 3-2		P4-6	BCD Data 2
17	" 3-1		P4-5	BCD Data 1
18	NC			
19	"			
20	"			
21	"			
22	"			
A	Out 0-8			
B	" 0-7			
C	" 0-6			
D	" 0-5			
E	" 0-4			
F	" 0-3			
H	" 0-2	TTY Card	JX-12/Jx-14	
J	" 0-1	TTY Card	JX-11/JX-9	
K	NC			
L	Out 2-8			
M	" 2-7			
N	" 2-6	to	P4-10	(+/- Lite)
P	" 2-5		P4-9	Lite Enable
R	" 2-4		P4-4	Lite MUX 1000
S	" 2-3		P4-3	Lite MUX 0100
T	" 2-2		P4-2	Lite MUX 0010
U	" 2-1		P4-1	Lite MUX 0001
V	NC			
W	"			
X	"			
Y	"			
Z	"			

ADL PIN CONNECTIONS

PROLOG SYSTEM 44 Pin INPUT Plug (On Top of Card Rack)

CODE.....

Pin Ident.
No.

1	In 1-8	to	P1-8,	A/D Bit	7
2	" 1-7		P1-7,	" "	8
3	" 1-6		P1-6,	" "	9
4	" 1-5		P1-5,	" "	10
5	" 1-4		P1-4,	" "	11
6	" 1-3		P1-3,	" "	12
7	" 1-2		P1-2,	" "	13
8	" 1-1		P1-1,	" "	14 (LSB)

9 NC

10 In 3-3 NC

11 " 3-7 NC

12 " 3-6 NC

13 " 3-5 to P2-5, Kyb'd Flag

14 " 3-4 P2-4, Kyb'd (1000)

15 " 3-3 P2-3, " (0100)

16 " 3-2 P2-2, " (0010)

17 " 3-1 P2-1, " (0001)

18 NC

19 "

20 "

21 "

22 "

A In 0-8

B " 0-7

C " 0-6

D " 0-5

E " 0-4

F " 0-3

H " 0-2

J " 0-1 to TTY Card (JX-17)

K NC

L In 2-8 to P1-16 NC

M " 2-7 P1-15, A/D EOC (end of conversion)

N " 2-6 P1-14, A/D Bit 1 (MSB)

P " 2-5 P1-13, " " 2

R " 2-4 P1-12, " " 3

S " 2-3 P1-11, " " 4

T " 2-2 P1-10, " " 5

U " 2-1 P1-09, " " 6

V NC

W "

X "

Y "

Z "

APPENDIX C

MATHEMATICS PACKAGE

Floating point (F.P.) binary numbers are used internally for most internal arithmetic functions. The method is fully explained in the following excerpts from the INTEL Users Library [3].

8008 BINARY FLOATING POINT SYSTEM

ARITHMETIC AND UTILITY PACKAGE

THE ARITHMETIC AND UTILITY SUBROUTINE PACKAGE OF THE 8008 BINARY FLOATING POINT SYSTEM CONTAINS SUBROUTINES FOR PERFORMING THE BASIC ARITHMETIC AND UTILITY OPERATIONS AVAILABLE IN THE SYSTEM.

THE ARITHMETIC AND UTILITY PACKAGE IS CONTAINED IN 768 CONSECUTIVE WORDS OF MEMORY (3 BANKS OF ROM) AND DOES NOT REQUIRE THAT ANY OTHER SOFTWARE BE PRESENT IN MEMORY. THIS PACKAGE USES THE FIRST 54 WORDS OF A BANK OF RAM AS SCRATCHPAD MEMORY.

THE INDIVIDUAL SUBROUTINES INCLUDED IN THE ARITHMETIC AND UTILITY PACKAGE OF THE FLOATING POINT SYSTEM ARE DESCRIBED IN DETAIL BELOW.

8008 BINARY FLOATING POINT SYSTEM

THE 8008 BINARY FLOATING POINT SYSTEM CONSISTS OF A SET OF SUBROUTINES DESIGNED TO PERFORM OPERATIONS ON NUMERIC QUANTITIES REPRESENTED IN A SPECIFIC NOTATION. SUBROUTINES ARE PROVIDED TO PERFORM A VARIETY OF ARITHMETIC AND RELATED OPERATIONS.

THE SUBROUTINES ARE DESIGNED TO BE STORED AND EXECUTED IN READ-ONLY-MEMORY(ROM) AND REQUIRE THE FIRST PORTION OF A BANK OF READ-WRITE-MEMORY(RAM) FOR SCRATCHPAD MEMORY. THE SUBROUTINES ARE SEPARATED INTO A NUMBER OF PACKAGES, EACH CONTAINING SUBROUTINES FOR A GROUP OF RELATED OPERATIONS. THE AMOUNT OF MEMORY(ROM AND RAM) REQUIRED FOR INSTALLATION OF THE SYSTEM IS DEPENDENT UPON THE COMBINATION OF PACKAGES TO BE USED. SCRATCHPAD MEMORY IS INITIALIZED BY A UTILITY SUBROUTINE WHICH MUST BE EXECUTED BEFORE OTHER SUBROUTINES ARE EXECUTED THE FIRST TIME.

IN GENERAL, THE SUBROUTINES HAVE SIMILAR ENTRY AND EXIT CONDITIONS. UNLESS SPECIFIED DIFFERENTLY IN THE DESCRIPTION OF A SPECIFIC SUBROUTINE, THE SUBROUTINES HAVE THE FOLLOWING CHARACTERISTICS.

SUBROUTINES REQUIRING ONE OPERAND TAKE IT FROM AN INTERNAL FLOATING POINT ACCUMULATOR. SUBROUTINES REQUIRING TWO OPERANDS TAKE ONE FROM THE ACCUMULATOR AND THE OTHER FROM THE MEMORY LOCATION INDICATED BY THE CONTENTS OF THE H AND L REGISTERS UPON ENTRY. THE NUMERIC RESULT OF EACH OPERATION IS STORED IN THE ACCUMULATOR AND IS RETURNED TO THE CALLER IN THE A, B, C, AND D REGISTERS.

UPON EXIT FROM THE ARITHMETIC SUBROUTINES, THE PROPERTIES OF THE RESULT ARE INDICATED BY THE SETTINGS OF THE CONTROL BITS.

CARRY BIT = 1	THE RESULT EXCEEDS THE CAPACITY OF THE ACCUMULATOR. THE OTHER CONTROL BITS, THE CONTENTS OF THE HARDWARE REGISTERS, AND THE CONTENTS OF THE ACCUMULATOR ARE MEANINGLESS. THIS SITUATION IS ALSO INDICATED BY A NON-ZERO QUANTITY BEING STORED IN A FLAG WORD.
CARRY BIT = 0	THE RESULT IS IN RANGE. THE ZERO AND SIGN BITS ARE PROPERLY SET, AND THE A, B, C, AND D REGISTERS CONTAIN A REPRESENTATION OF THE VALUE IN THE ACCUMULATOR.
ZERO BIT = 1	THE RESULT OF THE OPERATION IS ZERO OR A QUANTITY TOO SMALL TO BE REPRESENTED.
ZERO BIT = 0	THE RESULT IS NON-ZERO.
SIGN BIT = 1	THE RESULT IS NEGATIVE.
SIGN BIT = 0	THE RESULT IS POSITIVE.

DATA ARE REPRESENTED IN A NOTATION WHICH RECORDS EIGHT BITS OF EXPONENT, ONE BIT OF SIGN, AND TWENTY FOUR BITS OF FRACTION. THE LARGEST MAGNITUDE THAT CAN BE REPRESENTED IS APPROXIMATELY $3.6 * 10 ** 38$. THE SMALLEST NON-ZERO MAGNITUDE IS APPROXIMATELY $2.7 * 10 ** -39$. THE RESOLUTION OF THE NOTATION IS APPROXIMATELY $6.2 * 10 ** -8$. I.E., BETTER THAN SEVEN DECIMAL DIGIT PRECISION.

DATA VALUES ARE REPRESENTED IN FOUR CONSECUTIVE MEMORY WORDS WHICH MUST BE IN THE SAME BANK OF MEMORY. THE INTERPRETATION OF THESE WORDS IS SHOWN BELOW.

WORD 1 IF NON-ZERO, THIS WORD CONTAINS THE EXPONENT PLUS A BIAS OF 200 OCTAL. THE EXPONENT INDICATES THE POWER OF 2 BY WHICH THE FRACTION IS MULTIPLIED TO OBTAIN THE REPRESENTED VALUE. IF THIS WORD IS ZERO THE REPRESENTED VALUE IS ZERO AND WORDS 2, 3, AND 4 ARE MEANINGLESS.

WORD 2, BIT 7 THIS BIT INDICATES THE SIGN OF THE VALUE: 0 IF POSITIVE, 1 IF NEGATIVE.

WORD 2, BITS 6-0 THESE BITS PLUS AN ASSUMED 1 IN BIT 7 ARE THE MOST SIGNIFICANT BITS OF THE FRACTION. THE FRACTION IS STORED IN ABSOLUTE FORM (UNSIGNED) WITH THE RADIX POINT POSITIONED TO THE LEFT OF BIT 7. THE VALUE OF THE FRACTION IS THUS LESS THAN 1.0 AND EQUAL TO OR GREATER THAN 0.5.

WORD 3 THIS WORD CONTAINS THE SECOND MOST SIGNIFICANT EIGHT BITS OF THE FRACTION.

WORD 4 THIS WORD CONTAINS THE LEAST SIGNIFICANT EIGHT BITS OF THE FRACTION.

EXAMPLES OF DATA NOTATION.

VALUE	WORD1	WORD2	WORD3	WORD4	
0.0	000	xxx	xxx	xxx	X = DONT CARE
+1.0	201	000	000	000	
-1.0	201	200	000	000	
+0.1	175	114	314	314	
-100.1	207	310	063	063	

FLOATING POINT ACCUMULATOR.

THE FLOATING POINT ACCUMULATOR CONSISTS OF 5 SCRATCHPAD WORDS CONTAINING RESPECTIVELY THE ACCUMULATOR EXPONENT, THE ACCUMULATOR SIGN, AND THREE WORDS OF ACCUMULATOR FRACTION. THE EXPONENT IS RECORDED WITH A BIAS OF 200 OCTAL. AN EXPONENT WORD OF ZERO INDICATES THAT THE VALUE IN THE ACCUMULATOR IS ZERO AND THE REMAINING WORDS OF THE ACCUMULATOR ARE MEANINGLESS. THE SIGN WORD HOLDS 000 IF THE ACCUMULATOR IS NEGATIVE, 200 OCTAL IF POSITIVE. THE FRACTION IS RECORDED AS A NORMALIZED POSITIVE VALUE WITH THE RADIX POINT TO THE LEFT OF THE MOST SIGNIFICANT BIT OF THE FIRST FRACTION WORD.

OVERFLOW FLAG.

THE OVERFLOW FLAG WORD IS PROVIDED AS A CONVENIENCE TO THE USER OF THE FLOATING POINT SYSTEM. THE WORD IS INITIALLY SET TO ZERO AND MAY BE RESET TO ZERO BY THE USER AT ANY TIME. WHEN ANY OF THE SYSTEM SUBROUTINES DETECT AN OVERFLOW CONDITION THE OVERFLOW FLAG IS SET NON-ZERO. THUS THE USER MAY CLEAR THE FLAG, PERFORM A SEQUENCE OF FLOATING POINT OPERATIONS, AND CHECK THE FLAG TO DETERMINE IF AN OVERFLOW OCCURRED ANYWHERE IN THE SEQUENCE.

8008 BINARY FLOATING POINT SYSTEM

THE 8008 BINARY FLOATING POINT SYSTEM CONSISTS OF A SET OF SUBROUTINES DESIGNED TO PERFORM ARITHMETIC OPERATIONS ON NUMERIC QUANTITIES REPRESENTED IN MEMORY.

EACH NUMERIC QUANTITY OCCUPIES FOUR CONSECUTIVE WORDS (32 BITS) OF MEMORY. THE LARGEST MAGNITUDE THAT CAN BE REPRESENTED IS APPROXIMATELY 3.6 TIMES TEN TO THE 39TH POWER. THE SMALLEST NON-ZERO MAGNITUDE THAT CAN BE REPRESENTED IS APPROXIMATELY 2.7 TIMES TEN TO THE MINUS 39TH POWER. EACH NUMERIC QUANTITY IS REPRESENTED WITH A PRECISION OF ONE PART IN APPROXIMATELY 16,000,000.

THE SOFTWARE CONSTITUTING THE FLOATING POINT SYSTEM IS DIVIDED INTO TWO SECTIONS. EACH OF WHICH OCCUPIES 3 BANKS OF ROM OR RAM. SECTION 1 IS INDEPENDENT OF OTHER SOFTWARE. SECTION 2 IS OPERABLE ONLY WHEN SECTION 1 IS AVAILABLE IN MEMORY. IN ADDITION TO MEMORY REQUIRED FOR PROGRAM, 63 WORDS OF RAM ARE USED AS SCRATCHPAD.

SOFTWARE SECTION 1 CONTAINS THE FOLLOWING SUBROUTINES:

- LOD - LOAD SPECIFIED DATA INTO THE FLOATING POINT ACCUMULATOR.
- ADD - ADD SPECIFIED DATA TO THE FLOATING POINT ACCUMULATOR.
- SUB - SUBTRACT SPECIFIED DATA FROM THE FLOATING POINT ACCUMULATOR.
- MUL - MULTIPLY SPECIFIED DATA TIMES THE FLOATING POINT ACCUMULATOR.
- DIV - DIVIDE SPECIFIED DATA INTO THE FLOATING POINT ACCUMULATOR.
- TST - SET CONTROL BITS TO INDICATE ATTRIBUTES OF THE FLOATING POINT ACCUMULATOR.
- CHS - CHANGE THE SIGN OF THE FLOATING POINT ACCUMULATOR.
- ABS - SET THE SIGN OF THE FLOATING POINT ACCUMULATOR POSITIVE.
- STR - STORE IN SPECIFIED MEMORY THE VALUE IN THE REGISTERS AS RETURNED BY OTHER SUBROUTINES.
- INIT - MOVE CODE FROM ROM TO RAM IN PREPARATION FOR EXECUTION OF THE MUL AND DIV SUBROUTINES.

SOFTWARE SECTION 2 CONTAINS SUBROUTINES WHICH ARE USED TO CONVERT DATA BETWEEN THE BINARY FLOATING POINT FORMAT AND A DECIMAL FORMAT SUITABLE FOR ENTRY OR DISPLAY ON INPUT/OUTPUT EQUIPMENT. THE DECIMAL FORMAT IS STORED IN MEMORY AS A SERIES OF CHARACTERS. RELATIVELY SIMPLE INPUT/OUTPUT ROUTINES MAY BE USED TO INTERFACE THE MEMORY-RESIDENT CHARACTER STRINGS WITH ANY TYPE OF PHYSICAL I/O DEVICE.

THE CHARACTER STRINGS CONSIST OF BCD REPRESENTATIONS OF DECIMAL DIGITS AND ARBITRARY REPRESENTATIONS OF +, -, .. AN EXPONENTIAL SIGN(LETTER E), AND SPACE. CHARACTER STRINGS MAY NOT CROSS MEMORY BANK BOUNDARIES. AN INPUT STRING IS THEREFORE LIMITED TO 256 CHARACTERS. AN OUTPUT STRING CONSISTS OF 13 CHARACTERS.

THE OUT SUBROUTINE GENERATES CHARACTER STRINGS IN 2 FORMATS: THE CHOICE OF FORMAT DEPENDS ON THE MAGNITUDE OF THE VALUE REPRESENTED.

MAGNITUDES BETWEEN .1000000 AND 9999999. ARE REPRESENTED BY A SPACE OR MINUS SIGN, SEVEN DECIMAL DIGITS AND AN APPROPRIATELY POSITIONED DECIMAL POINT, AND FOUR SPACES.

MAGNITUDES OUTSIDE THE RANGE ARE REPRESENTED BY A SPACE OR MINUS SIGN, A VALUE BETWEEN 1.000000 AND 9.999999, AN EXPONENTIAL SIGN, AND A SIGNED TWO-DIGIT POWER OF TEN.

THE INP SUBROUTINE CONVERTS CHARACTER STRINGS IN EITHER OF THE ABOVE FORMATS, OR A MODIFIED VERSION OF THEM. THE LEADING SIGN MAY BE INCLUDED OR OMITTED. ANY NUMBER OF DIGITS MAY BE USED TO INDICATE THE VALUE. WITH OR WITHOUT AN INCLUDED DECIMAL POINT. IF A POWER-OF-TEN MULTIPLIER IS INDICATED IT MAY BE SIGNED OR UNSIGNED AND MAY CONTAIN ONE OR TWO DIGITS. AN INPUT STRING IS TERMINATED BY THE FIRST CHARACTER WHICH DEPARTS FROM THE FORMAT.

THE FOLLOWING ARE EXAMPLES OF INPUT AND CORRESPONDING OUTPUT CHARACTER STRINGS.

3.141593	3.141593
-.00000000000001	-1.000000F-13
+1.6E5	160000.0
123456789	1.234568E+08
54321E-10	5.432100E-06
-2718281828F-9	-2.718282

8008 BINARY FLOATING POINT SYSTEM

FORMAT CONVERSION PACKAGE

THE FORMAT CONVERSION PACKAGE OF THE 8008 BINARY FLOATING POINT SYSTEM CONTAINS SUBROUTINES FOR THE CONVERSION OF DATA BETWEEN THE FLOATING POINT SYSTEM NOTATION AND TWO OTHER FORMATS. THE NON-FLOATING-POINT FORMATS ARE FOUR WORD FIXED POINT FORMAT AND VARIABLE LENGTH CHARACTER STRING FORMAT.

THE FORMAT CONVERSION PACKAGE IS CONTAINED IN 512 CONSECUTIVE WORDS OF MEMORY (2 BANKS OF ROM) AND REQUIRES FOR ITS EXECUTION THAT THE ARITHMETIC AND UTILITY PACKAGE BE AVAILABLE IN MEMORY. THE COMBINATION OF THIS PACKAGE AND THE ARITHMETIC AND UTILITY PACKAGE USES THE FIRST 64 WORDS OF A BANK OF RAM AS SCRATCHPAD MEMORY.

THE FIXED POINT FORMAT DATA PROCESSED BY THIS PACKAGE CONSIST OF 32 BIT BINARY NUMBERS OCCUPYING FOUR WORDS. TWOS COMPLEMENT NOTATION IS USED TO REPRESENT NEGATIVE VALUES.

THE POSITION OF THE BINARY POINT RELATIVE TO THE BITS REPRESENTING THE VALUE IS DENOTED BY A BINARY SCALING FACTOR. THE BINARY SCALING FACTOR IS NOT NORMALLY RECORDED IN THE COMPUTER, BUT WHEN A FORMAT CONVERSION SUBROUTINE IS CALLED THE BINARY SCALING FACTOR MUST BE SPECIFIED (IN THE E REGISTER). A BINARY SCALING FACTOR OF ZERO INDICATES THE BINARY POINT IS IMMEDIATELY TO THE LEFT OF THE MOST SIGNIFICANT OF THE 32 BITS REPRESENTING THE VALUE. A BINARY SCALING FACTOR OF 32 INDICATES THE BINARY POINT IS IMMEDIATELY TO THE RIGHT OF THE LEAST SIGNIFICANT BIT. THE PERMISSIBLE RANGE OF THE BINARY SCALING FACTOR IS -128 (200 OCTAL) TO +127 (177 OCTAL).

THE CHARACTER STRING FORMAT DATA PROCESSED BY THIS PACKAGE CONSIST OF BINARY REPRESENTATIONS OF CHARACTERS OCCUPYING CONSECUTIVE WORDS OF MEMORY. A CHARACTER STRING MAY NOT CROSS A MEMORY BANK BOUNDARY. THE CHARACTERS WHICH MAY BE INCLUDED IN A CHARACTER STRING, AND THE CORRESPONDING OCTAL REPRESENTATIONS ARE LISTED BELOW.

DECIMAL DIGITS	000B-011B BCD DIGITS
SPACE	360B
+	373B PLUS
-	375B MINUS
.	376B DECIMAL POINT
EXPONENTIAL SIGN	025B LETTER E

(THESE OCTAL REPRESENTATIONS CAN BE CONVERTED TO THE CORRESPONDING ASCII CHARACTERS BY ADDING 060B TO EACH)

THE OUT SUBROUTINE GENERATES CHARACTER STRINGS IN TWO FORMATS. EACH CONSISTING OF 13 CHARACTERS. THE FORMAT USED IN A SPECIFIC CASE IS DEPENDENT UPON THE MAGNITUDE OF THE VALUE REPRESENTED.

SIGNIFICANCE INDEX

THE FLOATING POINT ADD AND SUBTRACT SUBROUTINES RETURN A SIGNIFICANCE INDEX TO THE USER WHEN THE RESULT OF THE OPERATION IS NOT ZERO. THIS INDEX GIVES AN INDICATION OF THE CHANGE IN THE VALUE OF THE ACCUMULATOR EXPONENT AS A RESULT OF THE ARITHMETIC OPERATION PERFORMED. IT IS USED PRIMARILY FOR COMPARISON OF TWO VALUES WHICH ARE EXPECTED TO BE EQUAL, BUT WHICH MAY DIFFER BY A SMALL AMOUNT DUE TO MEASUREMENT OR ROUND-OFF ERRORS. AS AN EXAMPLE, A SIGNIFICANCE INDEX OF 354 OCTAL (-20 DECIMAL) INDICATES THAT THE RESULT OF THE OPERATION IS SMALLER THAN THE OPERANDS BY A FACTOR OF APPROXIMATELY ONE MILLION (2^{20}). THE FLOATING POINT TEST, COMPLEMENT AND ABSOLUTE SUBROUTINES RETURN THE SIGNIFICANCE INDEX FROM AN IMMEDIATELY PRECEDING ADD OR SUBTRACT OPERATION.

HEXADECIMAL NOTATION [4]

Hexadecimal Notation is a convenient way of representing all sixteen combinations of four bits of information with a single character. The most popular character set for displaying Hexadecimal data are the characters 0 thru 9 to represent the binary combinations 0 thru 9 and A B C D E and F to represent the binary combinations 10 thru 15.

Hexadecimal Characters	Binary Bits 8 4 2 1	Decimal Characters
0	0 0 0 0	0
1	0 0 0 1	1
2	0 0 1 0	2
3	0 0 1 1	3
4	0 1 0 0	4
5	0 1 0 1	5
6	0 1 1 0	6
7	0 1 1 1	7
8	1 0 0 0	8
9	1 0 0 1	9
A	1 0 1 0	10
B	1 0 1 1	11
C	1 1 0 0	12
D	1 1 0 1	13
E	1 1 1 0	14
F	1 1 1 1	15

As an extension of this technique, all 256 combinations of 8 bits can be represented by two hexadecimal characters as shown in the following examples.

Hexadecimal Characters	Binary Bits	Decimal Characters
00	0000 0000	0
01	0000 0001	1
3E	0011 1110	52
42	0100 0010	66
E1	1110 0001	225
FF	1111 1111	255

Going further, all 4096 combinations of 12 bits can be represented by three Hexadecimal characters. This technique can be extended indefinitely, adding a Hexadecimal character for each four bits of information.

LIST OF REFERENCES

1. Russell, R. W., A Design Study for a Center Plate Mount for a Wind-tunnel Model, M. S. Thesis, Naval Postgraduate School, Monterey, California, 1977.
2. Englehardt C. D., Data Acquisition System for Unsteady Aerodynamic Investigation, M. S. Thesis, Naval Postgraduate School, Monterey, California, 1977.
3. Intel Corporation, MCS User's Library, p. 8-7, Intel, 1972.
4. Biewer, M, The Designers Guide To Programmed Logic, p. 1-1 to 6-0, Prolog Corporation, 1975.

INITIAL DISTRIBUTION LIST

	No. Copies
1. Defense Documentation Center Cameron Station Alexandria, Virginia 22314	2
2. Library, Code 0142 Naval Postgraduate School Monterey, California 93940	2
3. Department Chairman, Code 67 Department of Aeronautics Naval Postgraduate School Monterey, California 93940	1
4. CDR David Caswell, USN, Code 67C1 Department of Aeronautics Naval Postgraduate School Monterey, California 93940	1
5. Professor L. V. Schmidt, Code 67Sx Department of Aeronautics Naval Postgraduate School Monterey, California 93940	1
6. LT John David Casko, USN 8 Meyers Street Putnam, Connecticut 06260	1

THE HISTORY OF THE

REIGN OF

CHARLES THE FIRST

BY

JOHN BURNET

OF

THE UNIVERSITY OF OXFORD

IN TWO VOLUMES

THE FIRST

OF

THE SECOND

OF

THE THIRD

OF

OF

OF

Thesis
C2749
c.1

Casko

A microprocessor controlled automatic data logging system (ADL).

171709

8 JUN 78
14 MAY 81
14 MAR 89
6 NOV 92

27002
32404
39240

Thesis
C2749
c.1

Casko

A microprocessor controlled automatic data logging system (ADL).

171709

thesC2749

A microprocessor controlled automatic da



3 2768 002 09085 4

DUDLEY KNOX LIBRARY